

# User's Manual



**HDMI-TPS-RX110AY** 

HDBaseT™ Multimedia Extender

# **Important Safety Instructions**

# Class II apparatus construction.

The equipment should be operated only from the power source indicated on the product.

To disconnect the equipment safely from power, remove the power cord from the rear of the equipment, or from the power source. The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

There are no user-serviceable parts inside of the unit. Removal of the cover will expose dangerous voltages. To avoid personal injury, do not remove the cover. Do not operate the unit without the cover installed.

The appliance must be safely connected to multimedia systems. Follow instructions described in this manual.

#### Ventilation

For the correct ventilation and to avoid overheating ensure enough free space around the appliance. Do not cover the appliance, let the ventilation holes free and never block or bypass the ventilators (if any).

#### WARNING

To prevent injury, the apparatus is recommended to securely attach to the floor/wall or mount in accordance with the installation instructions. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus. No naked flame sources, such as lighted candles, should be placed on the apparatus.

# **Waste Electrical & Electronic Equipment WEEE**

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the



retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

# **Common Safety Symbols**

Symbol	Description	
===	Direct current	
$\sim$	Alternating current	
	Double insulation	
A	Caution, possibility of eletric shock	
A	Caution	

HDMI-TPS-RX110AY – User's Manual

# **Symbol Legend**

The following symbols and markings are used in the document:

WARNING! Safety-related information which is highly recommended to read and keep in every case!

**ATTENTION!** Useful information to perform a successful procedure; it is recommended to read.

INFO: A notice which may contain additional information. Procedure can be successful without reading it.

DEFINITION: The short description of a feature or a function.

TIPS AND TRICKS: Ideas which you may have not known yet but can be useful.


# **Navigation Buttons**



Go back to the previous page. If you clicked on a link previously, you can go back to the source page by clicking the button.



Navigate to the Table of Contents.



Step forward to the next page.

# **Document Information**

This User's Manual applies to the following versions of the mentioned software, firmware, and hardware:

Item	Version
Lightware Device Controller (LDC) software	1.20.0b5
Lightware Device Updater (LDU) Software	1.5.2b3
Controller firmware	1.2.0
Hardware	1.2

Document revision: **2.2** Release date: 31-10-2018

Editor: Judit Barsony

# **Table of Contents**

1. IN	TRODUCTION	
1.1.	DESCRIPTION	
1.2.	COMPATIBLE DEVICES	
	Box Contents	
1.4.	FEATURES	
1.5.	TYPICAL APPLICATION	
2. IN	STALLATION	
2.1.	MOUNTING OPTIONS	
	1. 1U High Rack Shelf	
	2. Under-desk Double Mounting Kit	
2.2.	CONNECTING STEPS	
3. PF	RODUCT OVERVIEW	1
3.1.	FRONT VIEW	1
3.2.	REAR VIEW	1
	ELECTRICAL CONNECTIONS	
	1. DC 12V Connection	
	2. HDMI Connector	
3.3.	3. Analog Audio Output	1
	4. Ethernet Connector (TPS and LAN Ports)	
	5. USB Connector	
	6. IR Connector	
	7. RS-232 Connector	
	8. Relay Connector	
	TPS RECEIVER CONCEPT	
	PORT DIAGRAM	
	TPS Interface	
	AUDIO INTERFACE	
	1. Audio Input	
	Audio Output Modes      Audio Options - Example	
	Video Interface	
	CONTROL FEATURES	
	Serial Interface	
	2. IR Interface	
	3. USB Control Interface	
	Ethernet Control Interface	
	5. Relay Interface	
	FURTHER BUILT-IN FEATURES.	
	0.1. Automatically Launched Actions – The Event Manager	
	0.2. Receiver Cloning – Configuration Backup and Restore	
	D.3. Remote Firmware Upgrade of Connected Lightware Devices	

4. OPE	ERATION	1
4.1. F	RONT PANEL - SPECIAL FUNCTIONS	1
	Programmable Function Button	
	Enable Dynamic (DHCP) IP Address	
	Reset to Factory Default Settings	
	Reseting the Device	
	Entering Bootload Mode	
	OFTWARE CONTROL MODES	
	TWARE CONTROL - LIGHTWARE DEVICE CONTROLLER	
	STALL AND UPGRADE	
	STABLISHING THE CONNECTION	
	ORT PARAMETERS MENU	
	. Video Tab	
	. Audio Tab	
	IAGNOSTIC TOOLS	
	Frame Detector	
	. Cable Diagnostics	
5.5. E	DID Menu	2
	. EDID Operations	
	. EDID Summary Window	
	. Editing an EDID	
	. Creating an EDID - Easy EDID Creator	
	ONTROL MENU	
	. RS-232	
	. Relays	
	. Ethernet	
	. Infra	
	VENT MANAGER	
	. The Event Editor	
5.7.2	. Create or Modify an Event	2
	. Special Tools and Accessories	
5.7.4	. Clear One or More Event(s)	3
	Export and Import Events	
5.7.6	Event Creating - Example	3
5.8. S	ETTINGS MENU	3
5.8.1	. Status	3
5.8.2	. Network	3
5.8.3	. Backup	3
5.8.4	. System	3
	ONFIGURATION CLONING (BACKUP TAB)	
	. Cloning Steps in a Nutshell	
	. Save the Settings of the Device (Backup)	

5.9.3. Upload the Settings to a Device (Restore)	33
5.9.4. Create and Restore Backups from the Device Memory	34
5.10. ADVANCED VIEW WINDOW	34
6. LW2 PROGRAMMERS' REFERENCE	35
6.1. LW2 Protocol Description	35
6.2. GENERAL LW2 COMMANDS	
6.2.1. View Product Type	35
6.2.2. Query Control Protocol	35
6.2.3. View Firmware Version of the CPU	36
6.2.4. Connection Test	36
6.2.5. View Serial Number	
6.2.6. Compile Time	36
6.2.7. View Installed Board	36
6.2.8. View Firmware for All Controllers	36
6.2.9. Restart the Device	
6.2.10. Query Health Status	
6.2.11. Restore Factory Default Settings	
6.3. PORT SETTINGS	
6.3.1. Mute Specified Output	
6.3.2. Unmute Specified Output	
6.3.3. Lock the Output	
6.3.4. Unlock the Output	
6.3.5. View Connection State on The Output	
6.3.6. View Crosspoint Size	
6.4. Network Configuration	
6.4.1. Query the Current IP Status	
6.4.2. Set the IP Address	
6.4.3. Set the Subnet Mask	
6.4.4. Set the Gateway Address	
6.4.5. Apply Network Settings	
6.5. RS-232 SETTINGS	
6.5.1. Set RS-232 Mode	
6.5.2. Set Local RS-232 Parameters	
6.5.3. Set Link RS-232 Parameters	
6.5.4. Set Local RS-232 Control Protocol Port	
6.5.5. Set Link RS-232 Control Protocol Port	
6.6. RELAY SETTINGS	40
6.6.1. Query Relay Connection State	
6.6.2. Set Relay Connection State	
6.7. LW2 COMMANDS - QUICK SUMMARY	

# **Table of Contents**

7. LW3 PROGRAMMERS' REFERENCE	4
7.1. OVERVIEW	4
7.1.1. Elements of the Tree Structure	
7.1.2. Escaping	
7.1.3. Error Messages	
7.1.4. Prefix Summary	4
7.2. THE TREE STRUCTURE OF THE RECEIVER	4
7.3. LW3 COMMANDS	4
7.3.1. Get Command	4
7.3.2. Set Command	4
7.3.3. Invocation	
7.3.4. Manual	
7.3.5. Signature	
7.3.6. Subscription	
7.3.7. Notifications about the Changes of the Properties	
7.4. FORMAL DEFINITIONS	
7.5. SYSTEM COMMANDS	
7.5.1. Query the Product Name	
7.5.2. Set the Device Label	
7.5.3. Query the Serial Number	
7.5.4. Query the Firmware Version	
7.5.5. Identify the Device	
7.5.6. Resetting the Device	
7.5.7. Restore the Factory Default Settings	
7.6. VIDEO PORT SETTINGS	
7.6.1. Query the Status of Source Port	
7.6.2. Query the Status of Destination Port	
7.6.3. Mute Input Port	
7.6.4. Unmute Input Port	
7.6.5. Lock Input Port	
7.6.6. Unlock Input Port	
7.6.7. Mute Output	
7.6.8. Unmute Output	
7.6.10. Unlock Output	
7.6.11. HDCP Setting (Input Port)	
7.6.12. HDCP Setting (Input Port)	
7.6.13. Test Pattern Generator	
7.6.14. HDMI Mode Settings (Output Port)	
7.6.15. Query the Recent TPS Mode	
7.6.16. TPS Mode Settings	
7.0.10. 173 Mode Settings	
7.7.1. Query the Status of Source Port	
7.7.1. Query the status of source fort	5

Query the Status of Destination Port	54
Mute Output	55
Unmute Output	
Analog Audio Output Level Settings by Steps	56
Query the IP Address	56
Change the IP Address (Static)	56
Query the Subnet Mask	57
Query the Gateway Address	57
S-232 Port Configuration	57
Protocol Setting	57
BAUD Rate Setting	57
Databit Setting	57
Stopbits Setting	58
Parity Setting	58
RS-232 Operation Mode	58
ENDING MESSAGE VIA THE COMMUNICATION PORTS	58
. Sending Message via TCP Port	
. Sending Message via UDP Port	59
. Sending Message via an RS-232 Port	59
NFRARED PORT CONFIGURATION	60
. Enable Command Injection Mode	60
. Change Command Injection Port Number	60
. Enable/Disable Output Signal Modulation	60
RELAY PORT SETTINGS	60
. Set Relay Connection State	60
DID MANAGEMENT	60
. Query the Emulated EDIDs	60
. Query the Validity of a Dynamic EDID	61
. Query the Preferred Resolution of an User EDID	61
Emulating an EDID to an Input Port	
Copy an EDID to User Memory	
. Deleting an EDID from User Memory	
W3 COMMANDS - QUICK SUMMARY	
	Unmute Output

8. FIRMWARE UPGRADE	65
8.1. ABOUT THE FIRMWARE PACKAGE (LFP FILE)	
8.2. Short Instructions	
8.3. Install and Upgrade	
8.4. Detailed Instructions	
8.4.1. Establish the Connection	
8.4.2. Start the LDU and Follow the Instructions	
8.5. KEEPING THE CONFIGURATION SETTINGS	
8.6. REMOTE FIRMWARE UPGRADE OF CONNECTED LIGHTWARE DEVICE	s70
9. TROUBLESHOOTING	71
9.1. USE CASE STUDIES	71
9.2. How to Speed Up the Troubleshooting Process	
10. TECHNOLOGIES	74
10.1. EDID MANAGEMENT	74
10.1.1. Understanding the EDID	74
10.1.2. Advanced EDID Management	
10.2. HDCP MANAGEMENT	
10.2.1. Protected and Unprotected Content	75
10.2.2. Disable Unnecessary Encryption	
10.3. PIXEL ACCURATE RECLOCKING	76
11. APPENDIX	77
11.1. SPECIFICATION	
11.2. INPUT/OUTPUT PORT NUMBERING	
11.3. CONTENT OF BACKUP FILE	
11.4. Factory Default Settings	
11.5. MAXIMUM EXTENSION DISTANCES	
11.6. MECHANICAL DRAWINGS	
11.7. AUDIO CABLE WIRING GUIDE	
11.8. FACTORY EDID LIST	
11.9. FURTHER INFORMATION	_



# Introduction


Thank you for choosing Lightware's HDMI-TPS-RX110AY receiver. In the first chapter we would like to introduce the device highlighting the most important features in the below listed sections:

- DESCRIPTION
- COMPATIBLE DEVICES
- **▶** Box Contents
- ▶ FEATURES
- TYPICAL APPLICATION

# 1.1. Description

A small size HDBaseT™ TPS receiver unit is being developed in the Lightware works with one PoE capable TPS input and a single HDMI output. The unit is full 4K/UHD and 3D capable and HDCP compliant. The HDMI audio is de-embedded to the balanced audio output via a Phoenix (Euroblock) connector, the audio port has volume and balance control. The built-in Event Manager feature and the dual Relay module of the device are both configurable via the Lightware Device Controller software. Further control options are served by the USB, RS-232, IR (in and out) and Ethernet ports.

### **Model Denomination**



# 1.2. Compatible Devices

The receiver is compatible with other Lightware TPS transmitters, matrix TPS and TPS2 boards, 25G TPS2 boards, as well as third-party HDBaseT-extenders, displays, but not compatible with the phased out TPS-90 extenders.

**ATTENTION!** The receiver is PoE-compatible (Power over Ethernet, can be powered remotely via using CATx cable) but the device can only receive power and cannot send power other PoE-compatible devices. Only the TPS connector is PoE-compatible, Ethernet port cannot receive power.




The receiver is compatible with any third-party HDBaseT<sup>™</sup> device.

HDBaseT™ and the HDBaseT Alliance logo are trademarks of the HDBaseT Alliance.

### The List of Compatible Lightware Devices

- MX Modular matrix frames MX-TPS/TPS2-0B
- 25G Modular matrix frames 25G-TPS2-0B
- Standalone TPS matrix frames MMX6x2-HT series
- TPS Transmitters:
- HDMI-TPS-TX95/97
- DVI-HDCP-TPS-TX95/97
- UMX-TPS-TX100 series
- WP-UMX-TPS-TX100 series
- SW4-TPS-TX240
- HDMI-TPS-TX200 series
- DVI-HDCP-TPS-TX200 series
- DP-TPS-TX200 series
- Single port standalone TPS power injector TPS-PI-1P1

# 1.3. Box Contents



HDMI-TPS-RX110AY receiver



12V DC adaptor with interchangeable plugs



Phoenix® Combicon 3-pole connector



Phoenix® Combicon 4-pole connector



Phoenix® Combicon 5-pole connector



Infrared detector unit



Infrared emitter unit



Safety & warranty info, Quick Start Guide

1. Introduction HDMI-TPS-RX110AY - User's Manual

# 1.4. Features



### 3D and 4K Support

High bandwidth allows extension of resolutions up to 4K and even 3D sources and displays are supported.



### Signal Transmission up to 170 m

Video and audio signal transmission (HDMI, Ethernet, RS-232, and Infra-Red over a single CAT5e...CAT7e cable.



### **Pixel Accurate Reclocking**

Each output has a clean, jitter free signal, eliminating signal instability and distortion caused by long cables or connector reflections.



### Frame Detector and Signal Analysis

The exact video and audio signal format can be determined such as timing, frequencies, scan mode, HDCP encryption, color range, color space and audio sample rate.



### **HDCP-compliant**

The receiver fulfills the HDCP standard. HDCP capability on the digital video inputs can be disabled when non-protected content is extended.



### **Built-in Event Manager**

The Event Manager tool takes care of all the necessary control in a smaller configuration by performing predefined actions in response to device status changes. Hence, in a less complex environment, there is no need to invest in additional control solutions, which makes the receiver the best choice for numerous applications.



#### Remote Power

The receiver is PoE-compatible and can be powered locally by the supplied power adaptor, or remotely via the TPS connection (through the CATx cable) with a compatible power source equipment, e.g. MMX6x2-HT series matrix switchers and TPS2 matrix boards.



### Bi-directional RS-232 Pass-through

AV systems can also contain serial port controllers and controlled devices. Serial port pass-through supports any unit that works with standard RS-232.



#### Relay

2x controllable relay modules up to 30V, 1A support.




#### **Ethernet Control**


Multiple simultaneous TCP/IP connections are available with a simple ASCII-based protocol for controlling, configuring the receiver or perform a firmware upgrade.

# 1.5. Typical Application

### **Standalone Application Diagram**



### **Integrated System Diagram**



2. Installation HDMI-TPS-RX110AY – User's Manual



# Installation

The chapter is about the installation of the device and connecting to other appliances, presenting also the mounting options and further assembly steps:

- MOUNTING OPTIONS
- **▶** CONNECTING STEPS

# 2.1. Mounting Options

To mount the receiver Lightware supplies optional accessories for different usage. There are two kinds of mounting kits with similar fixing method. The receiver has two mounting holes with inner thread on the bottom side; see the bottom view in the Mechanical Drawings section. Fasten the device by the screws enclosed to the accessory:



Under-desk double mounting kit



1U high rack shelf


The Under-desk double mounting kit makes easy to mount a single device on any flat surface, e.g. furniture. 1U high rack shelf provides mounting holes for fastening two half-rack or four quarter-rack sized units. Pocket-sized devices can also be fastened on the shelf. To order mounting accessories please contact sales@lightware.com.

WARNING! Always use the supplied screws. Using different (e.g. longer) ones may cause damage to the device.

INFO: The receiver is half-rack sized.

# 2.1.1. 1U High Rack Shelf


Allows rack mounting for half-rack, quarter-rack and pocket sized units.



1U high rack shelf provides mounting holes for fastening two half-rack or four quarter-rack sized units. Pocket sized devices can also be fastened on the self.

# 2.1.2. Under-desk Double Mounting Kit


The UD-kit double makes it easy to mount a single receiver on any flat surface (e.g. furniture).



INFO: The chipboard screws are not supplied with the mounting kit.


2. Installation HDMI-TPS-RX110AY – User's Manual

# 2.2. Connecting Steps



- CATX Connect the compatible transmitter or the matrix output board and the receiver unit by a CATx cable via the TPS connectors.
- HDMI Connect the sink device to the HDMI output port.
- Audio Optionally connect an audio device (e.g. an audio amplifier) to the audio output port. See the wiring guide for the Phoenix 5-pole connector in the Audio Cable Wiring Guide section.
- Optionally for Infrared extension:
  - Connect the IR emitter to the IR OUT port of the receiver.
  - Connect the IR detector to the IR IN port of the receiver.
- USB Optionally connect the receiver to a control device (e.g. laptop) with an USB mini cable.
- RS-232 Optionally for RS-232 extension: connect a controller/controlled device (e.g. touch panel) to the RS-232 port.
- Optionally connect the receiver to a LAN network in order to control the device.
- Relay Optionally for relays: connect a controlled device(s) (e.g. a projection screen) to the relay port.
- Power See powering options on the next section.

### **Powering Options**



- (A) Using local PSU connect the power adaptor to the DC input on the receiver first, then to the AC power socket.
- **B** Using PoE with connecting a transmitter: connect the TPS IN (PoE) port of the receiver to the TPS+PoE output port of the TPS-PI-1P1 power injector by a CATx cable as well as connect the TPS output port of the transmitter to the TPS port of the TPS-PI-1P1 by a CATx cable.
- **C** Using PoE with connecting a matrix or an output board: connect the TPS IN (PoE) port of the receiver to the PoE-compatible TPS output port of the matrix or output board by a CATx cable.

**ATTENTION!** In case of connecting the receiver to an output board of the matrix always connect an external PSU to the board. For the detailed information please read the user's manual of the matrix.

ATTENTION! The Ethernet port does not support PoE. Only the TPS port support PoE function.

INFO: If both remote and local power sources are connected, the remote power will be used.



# **Product Overview**

The following sections are about the physical structure of the device, input/output ports and connectors:

- FRONT VIEW
- REAR VIEW
- **▶** ELECTRICAL CONNECTIONS
- **▶** TPS RECEIVER CONCEPT
- ▶ PORT DIAGRAM
- ▶ TPS INTERFACE
- AUDIO INTERFACE
- VIDEO INTERFACE
- **▶** CONTROL FEATURES
- **▶** FURTHER BUILT-IN FEATURES

# 3.1. Front View



1	Relay	4-pole Phoenix connector for relay ports.
		Pin assignment can be found in the Relay

Connector section.

2 IR IN and OUT 3-pole TRS connector, also known as

3.5 mm (1/8") jack plug for optional IR receiver (IR IN) and transmitter (IR OUT). Pin assignments can be found in the IR

Connector section.

3 USB USB interface for LDC connection to

control the receiver.

4 RS-232 3-pole Phoenix connector for controlling

the device with LDC or third-party control systems. Pin assignment can be found in

the RS-232 Connector section.

Ethernet Locking RJ45 connector for controlling

the device with LDC or third-party control systems and LDU for firmware upgrade.

Status LEDs The LEDs give immediate feedback about

current state of the device. See below the

details.

Reset button Pressing reset button reboots the

extender.

Special functions are available with this button (switch to bootload mode, enable

DHCP, restore factory default settings). For the details about special functions see the Front Panel - Special Functions section. Status LEDs

LIVE



**OFF:** The device is not powered.

**BLINKING:** (slow; 1 sec): Device is powered and

operational.

(fast; 0,5 sec): Device is in bootload

mode.

**ON:** The device is powered but not

operational.

**RS-232** 



**OFF:** RS-232 ports (local and link) in Pass-

through mode.

**BLINKING:** Command Injection mode is active.

**ON:** RS-232 ports (local and link) are in

Control mode.

**AUDIO OUT** 



**BLINKING:** 

**OFF:** Embedded audio is not present or

analog output is muted.

Embedded audio format is not

supported for audio de-embedding.

**ON:** Embedded audio is present and de-

embedded.

**TPS LINK** 



**OFF:** No TPS link between transmitter

and receiver.

**BLINKING:** Device is in low power mode or in

Ethernet fallback mode.

**ON:** TPS link is established, HDBaseT or

Long Reach mode is active.

# 3.2. Rear View



**DC 12V IN** 

Local power in; connect the output of the supplied 12V DC power adaptor. For more details see next section.

TPS IN (PoE)

Locking RJ45 connector. Connect a twisted pair cable between the transmitter and the receiver. Remote powering is also available through this connector. Maximum CATx cable distances can be found in the Maximum Extension Distances section.

3 SIGNAL status LED

The LED gives immediate feedback about current state of the HDMI output signal. See the legend below.

4 HDMI OUT

Connect an HDMI cable between the receiver and the local sink device. Applied cable shall not be more, than 30 m (when the signal is 1080p) and 20 m (when the signal is 4K).

6 HDCP status LED

The LED gives immediate feedback about current state of HDCP. See the legend next to the table.

**6** AUDIO OUT

5-pole Phoenix connector for asymmetric analog audio output. Pin assignment can be found in the next section.

### **TPS Input LEDs**



**OFF:** Remote power (PoE) is inactive, device is powered

locally.

**ON:** Remote power is active.

 $(\mathcal{P})$ 

**OFF:** No TPS link between the

transmitter and receiver.

**BLINKING:** Device is in low power

mode or Ethernet fallback

mode.

**ON:** TPS signal is present.

# **SIGNAL LED for HDMI Output**



OFF: Output signal is not present or

muted.

**ON:** Signal is present.

# **HDCP LED for HDMI Output**



**OFF:** Output signal is not HDCP-

encrypted.

**BLINKING:** Non-HDCP capable device is connected, encrypted signal is

replaced with red screen

replaced with red screen.

**ON:** Output signal is HDCP-encrypted.

# 3.3. Electrical Connections

## 3.3.1. DC 12V Connection



Locking DC connector

Do not forget to turn the plug clockwise direction before disconnecting the power adaptor.

WARNING! Always use the supplied 12V power adaptor. Warranty void if damage occurs due to use of a different power source.


### 3.3.2. HDMI Connector

The extender provides standard 19 pole HDMI connector for output. Always use high quality HDMI cable for connecting sources and displays.



# 3.3.3. Analog Audio Output

5-pole Phoenix connector is used for balanced analog audio output. Unbalanced audio signals can be connected as well. For unbalanced output connect + and ground to the source and connect – to the ground.



Pin nr.	Signal
1	Left+
2	Left-
3	Ground
4	Right-
5	Right+
•	



Analog audio connector and plug pin assignments

## **Compatible Plug Type**

Phoenix® Combicon series (3.5mm pitch, 5-pole), type: MC 1.5/5-ST-3.5.

You can find more information about analog audio function in the Audio Interface section. Audio cable wiring guide is in the Audio Cable Wiring Guide section.

# 3.3.4. Ethernet Connector (TPS and LAN Ports)

The extender provides standard RJ45 connectors for TPS IN and LAN ports. Always use high quality Ethernet cable for connecting transmitters and receivers. Maximum CATx cable distances can be found in the Maximum Extension Distances section.








RJ45 connector for LAN port RJ45 connector for TPS input port

### Wiring of TPS and LAN Cables

Lightware recommends the termination of LAN cables on the basis of TIA/EIA T 568 A or TIA/EIA T 568 B standards.







Pin	TIA/EIAT568 A	Color and name	TIA/EIAT568B	Color and name
1	•	white/green stripe	•	white/orange stripe
2		green solid	0	orange solid
3	0	white/orange stripe	•	white/green stripe
4		blue solid		blue solid
5	•	white/blue stripe		white/blue stripe
6	0	orange solid	•	green solid
7	•	white/brown stripe	•	white/brown stripe
8	•	brown solid	•	brown solid

You can find more information about TPS interface in the TPS Interface section.

### 3.3.5. USB Connector

The extender provides standard USB 2.0 mini B-type connector for software control purpose.



### 3.3.6. IR Connector

IR detector and IR emitter can be connected to the receiver with TRS (Tip, Ring, and Sleeve) connectors. They are also known as (3,5 mm or approx. 1/8") audio jack, phone jack, phone plug, and mini-jack plug. The pin assignments are the following for the detector and the emitter:


1 2 3		1	2-3
Detector - 3-pole TRS		Emitter - 2-pole TS	
1 Tip	Signal (active low)	1 Tip	+5V
2 Ring	GND	2 Ring	Signal (active low)
3 Sleeve	+5V	3 Sleeve	Signal (active low)

INFO: Ring pole of the emitter is optional. If your IR emitter has three-pole TRS plug, then the Ring and the Sleeve are the same signal (Output - ).

You can find more information about Infrared interface in the IR Interface section.

### 3.3.7. RS-232 Connector

The receiver contains a 3-pole Phoenix connector which is used for RS-232 serial connection.



Pin nr.	Signal
1	Ground
2	TX data
3	RX data



RS-232 connector pin assignments

# **Compatible Plug Type**


Phoenix® Combicon series (3.5mm pitch, 3-pole), type: MC1.5/3-ST-3.5.

You can find more information about RS-232 interface in the Serial Interface section.

# 3.3.8. Relay Connector

The receiver contains a 4-pole Phoenix connector which is used for relay connection.





	Pin nr.	Signal
]	1	Pin 1 for Relay 1
	2	Pin 2 for Relay 1
	3	Pin 1 for Relay 2
3	4	Pin 2 for Relay 2



## Relay connector pin assignment

INFO: The maximum ratings for each relay are 30V and 1A, AC/DC.

### **Compatible Plug Type**

Phoenix® Combicon series (3.5mm pitch, 4-pole), type: MC 1.5/4-ST-3.5.

You can find more information about relay interface in the Relay Interface section.

# 3.4. TPS Receiver Concept


HDMI-TPS-RX110AY is a multifunctional receiver with HDBaseT™ (TPS) technology. The device can be controlled via many kind of interfaces, e.g. Ethernet, USB, RS-232, and Infrared. The receiver is built with audio de-embedder and relay function.



Summary of the interfaces

# 3.5. Port Diagram

The following figure describes the port diagram of the device:



### Port diagram of HDMI-TPS-RX110AY receiver

The device receives HDMI/DVI, Ethernet, RS-232, Infrared signals on the TPS input line. A/V signals are processed in the HDBaseT<sup>™</sup> receiver unit. The audio de-embedder separates the digital audio and video signals. The digital video signal through the HDMI reclocker can be forwarded to the local sink device by the HDMI output port while digital audio signal is converted to analog by the digital-analog (D/A) converter and forwarded to the local audio sink device by the analog audio output port.

# 3.6. TPS Interface

The device is built with TPS (Twisted Pair Single) interface which are using HDBaseT<sup>™</sup> technology. It means the unit receives video, audio, Ethernet, RS-232, and Infrared signals via a single CATx cable.

# **TPS Interface Working Modes**

The TPS working mode between the transmitter and the receiver is determined by the mode set in them. Both devices TPS mode settings together determine the finally established TPS transmission mode.

The following TPS modes are defined in the receiver:

- Auto: The TPS mode is determined automatically.
- HDBaseT: Ideal for high resolution signals up to 4K.
- Long reach: Ideal for big distances up to 1080p@60Hz with extended cable lengths.
- LPPF1\*: Only RS-232 communication is transmitted (@ 9600 baud).
- LPPF2\*: Only RS-232 (@ 9600 baud) and Ethernet communication are transmitted.
- \* LPPF: Low Power Partial Functionality.

		Selected mode on RX side				
		LPPF1	LPPF2	HDBaseT	Long reach	Auto
e	LPPF1	LPPF1	LPPF1	LPPF1	LPPF1	LPPF1
mode side	LPPF2	LPPF1	LPPF2	LPPF2	LPPF2	LPPF2
, O)	HDBaseT	LPPF1	LPPF2	HDBaseT	Long reach	HDBaseT
Selected on TX	Long reach	LPPF1	LPPF2	Long reach	Long reach	Long reach
Š	Auto	LPPF1	LPPF2	HDBaseT	Long reach	HDBaseT **

<sup>\*\*</sup> If there is valid HDMI/DVI signal is on the TX side, the TPS mode will be HDBaseT on both side. If the transmitter does not transmits HDMI/DVI signal, the TPS mode will be changed to LPPF2 or LPPF1 automatically. Long reach mode is not available when both sides are set to Auto mode.

When using automatic operation mode selection, the device determines the mode of operation. If both halfs are set to Auto mode, the source side is the initiator. It will negotiate each state transition with its sink side partner.

When one of the devices is configured to manual operation mode selection, the other device may be placed in automatic mode. In this case, the mode transition negotiation is initiated by the host-managed device and the auto-mode device follows through. The allowed cable lengths and resolutions are listed in the Maximum Extension Distances section.

# 3.7. Audio Interface

# 3.7.1. Audio Input

The device can receive embedded audio signal on the TPS input line.

# 3.7.2. Audio Output Modes

The device can transmit two types of audio:


- Embedded (HDMI) and
- Analog balanced stereo audio.

# Audio de-embedding

The receiver has built-in audio de-embedder what means the device is able to receive HDMI signal with embedded audio via TPS line and can separate to video and audio signals on the output side.

**ATTENTION!** De-embedding function supports 2 channel PCM audio signals only. Other audio formats are not supported and de-embedding will not be successful.

## 3.7.3. Audio Options - Example



### The Concept

The source is a Blu-ray player which sends audio and video signals on HDMI to the transmitter. The receiver accepts the signal on the TPS line, the audio signal is still embedded. HDMI-TPS-RX110AY makes deembedding the AV signal to separated digital audio and analog audio signals and transmit them to the HD TV and the audio amplifier.


The following ways are available for the audio devices:

- The Receiver transmits the digital audio signal together with the video signal to the HDTV.
- The Receiver de-embeds the digital audio signal and converts it to analog one. It is transmitted to the Audio amplifier. So the HDTV provides the picture and Audio amplifier provides the sound. In this case digital audio on HDMI line needs to be muted.

# 3.8. Video Interface

The device can receive digital video signal via TPS line from any HDBaseT™ compliant transmitter, matrix or matrix board. On the output side the receiver transmits HDMI signal toward the sink.

### Video Interface - Example



### The Concept

The Receiver is connected to the Matrix which has two sources: a Blu-ray player and a PC. The input source can be selected in the matrix which transmits the video signal toward the receiver via the TPS interface.

# 3.9. Control Features

HDMI-TPS-RX110AY has several control functions. This chapter is about to present the possibilities through two simple layout examples.


# **System Control via Local Ethernet (Example)**



The following ways are available for device control:

- The System controller can communicate with the Receiver via the TPS line of the Transmitter with using LW2/LW3 protocol commands.
- The System controller can communicate directly with the Projector via their IP:port address.
- The **Receiver** can send a commands (e.g. as an action by the Event Manager) to the IP:port address of the **Projector** by using LW3 protocol methods.

### System Control via Local RS-232 (Example)




The following ways are available for controlling the devices:

- The System controller can communicate with LW2/LW3 protocol commands via the local RS-232 port of the Receiver.
- The **System controller** can send TCP or UDP messages to the IP:port address of the **Receiver** by using LW3 protocol methods.
- The Receiver can send LW3 protocol commands to the HDTV via the local RS-232 port.

#### 3.9.1. Serial Interface

### **Technical Background**

Serial data communication can be established via the local RS-232 port (Phoenix connector) or via the TPS lines. The RS-232 ports – which are connected to the CPU – can be configured separately (e.g. if the Baud rates are different, the CPU does the conversion automatically between the ports). The RS-232 port can be switched to Pass-through mode, Control mode, or Command Injection mode; see the figure below.



Block diagram of the serial interface

The following settings are defined:

- The Local and the TPS serial port is in Control mode.
- The Local and the TPS serial port is in Pass-through mode.
- The Local and the TPS serial port is in **Command Injection mode**.

INFO: All settings are available in the LDC software, see settings in the RS-232 section.

Only one mode can be used at the same time: Control mode, or Pass-through mode, or Command Injection mode. If you choose one of them, TPS serial link and local RS-232 port will operate in the same mode.

# Pass-through Mode

In pass-through mode, the given device forwards the data that is coming from one of its ports to another same type of port. The command is not processed by the CPU. Incoming serial data is forwarded from TPS input port to local RS-232 port and vica versa inside the receiver.


#### **Control Mode**

The incoming data from the given port is processed and interpreted by the CPU. The mode allows to control the receiver directly. LW2 or LW3 protocol commands are accepted – depending on the current port setting.

### **Command Injection Mode**

In this mode, the receiver works as an RS-232 bidirectional converter. The TPS signal is converted to RS-232 data and vice versa. TCP/IP port numbers are defined for the serial ports (TPS and local) for this purpose. E.g. the default Command Injection port number of the local RS-232 port is 8001. If a command is coming from the TPS interface which addresses to the port no. 8001, it will be transmitted to the Tx pin of the local RS-232 port. That works in the opposite direction of course and the method is the same on the serial interface of the TPS port as well.

### RS-232 Signal Transmission - Example



### **The Concept**

The System controller can send commands to the receiver through the TPS transmitter and is able to remote control the projector via RS-232.

# **Settings**


- System controller: wireless IP connection to the same Ethernet as the transmitter is connected to. Use
  a dedicated software tool (e.g. a terminal) which is suitable for sending commands via TCP/IP to a
  certain IP:port address.
- Transmitter: set the RS-232 mode to Command Injection on TPS output port. Set the further parameters (Baud rate, Data bits, etc.) in accordance with the specifications of the projector. The transmitter will transmit the RS-232 data toward the receiver.
- Receiver: set the RS-232 mode to Pass-through on RS-232 port.
- **Projector**: note the RS-232 port setting that is specified by the Manufacturer. Connect a suitable serial cable with the proper wiring.

### 3.9.2. IR Interface

**ATTENTION!** For the complete usage attach the supplied IR emitter unit to the IR OUT and the IR detector unit to the IR IN connectors.

### **Technical Background**

The Infrared signal transmission is similar to the serial data communication. The receiver contains dedicated IR I/O connection and also can transmit/receive IR signal via the TPS interface. The signal is in pronto HEX format in both cases.




Block diagram of the IR interface

The most trivial usage of the IR interface is the transparent mode: signal received or sent on local IR ports are transmitted directly on the TPS IR link port and vica versa. Beside of this there is an IR recognizer in the device where you can assign actions in Event Manager for. The third option is the command injection mode (like at serial interface in the previous section) where you can send IR commands over LAN. Command injection mode can be turned on and off by input/output ports.

INFO: All settings are available in the LDC software, see settings in the Infra section.

INFO: The modulation of output IR signal can be turned off or on by LW3 command, see the Enable/ Disable Output Signal Modulation section.

### IR Signal Transmission - Example



#### The Concept

An IR detector is attached to the Infrared input port of the Receiver and IR signals are sent by the Remote controller. The Receiver is connected to a compatible Transmitter built with IR output port via TPS line. An audio device is also connected to the audio output port of the receiver.

The following ways are available for controlling the devices:

- Transparent mode: IR signals are received over the local IR input port of the Receiver by the Remote controller. The signals transmitted further over the TPS line to the Transmitter which can control the Blu-ray player via an IR emitter.
- Event Manager usage: set an action in Event Manager that if the volume control buttons are pressed
  on the Remote controller, increase or decrease the volume of the analog audio port of the Receiver. In
  this case you can control the audio device via the Receiver remotely. See the details about the Event
  Manager settings in the Event Manager section.

#### 3.9.3. USB Control Interface

The device can be controlled over front panel USB mini B-type connector. This interface only supports LW3 protocol. The interface can be used to establish a connection to Lightware Device Controller software.

#### 3.9.4. Ethernet Control Interface

The device can be controlled over front panel Ethernet standard RJ45 connector which connected to LAN. This interface supports both LW2 and LW3 protocols.

The interface can be used to remote control the device with Lightware Device Controller and establish the connection to Lightware Device Updater software and perform firmware upgrade.


## 3.9.5. Relay Interface

HDMI-TPS-RX110AY receiver contains two relay modules which can be accessed by a 4-pole Phoenix connector. The relays can be controlled by Lightware protocol commands (LW3) and Event manager actions can be assigned to the port.

**ATTENTION!** The device built with normally open (N.O.) contact relays which means when the unit is not powered (DC plug is disconnected), the relays will open.

INFO: The default state of each relay ports is open.

### **Application of Relays - Example**



# The Concept

Ceiling lamp is turned off by Relay 1 and projection screen is rolled down by Relay 2 when signal received from the transmitter over TPS input line.

## **Settings of the Receiver**

- Relay 1: create an event in Event manager: when signal is present on Input 1 (I1) then set Relay 1 to be open. Also create another event when signal is not present on Input 1 (I1) then set Relay 1 to be closed.
- Relay 2: create an event in Event manager when signal is present on Input 1 (I1) then set Relay 2 to be closed. Also create another event when signal is not present on Input 1 (I1) then set Relay 2 to be open.


When Blu-ray player starts to play the presentation video, signal is received over TPS input line so Relay 1 opens which results turning off the lights, furthermore Relay 2 closes and the projection screen is rolled down. When the presentation is ended, signal ceases on the TPS input line, so Relay 1 closes which results turning on the lights, furthermore Relay 2 opens and projection screen returns to its enclosure.

See the details about the Event Manager settings in the Event Manager section.

### 3.10. Further Built-in Features

## 3.10.1. Automatically Launched Actions - The Event Manager

The Event Manager feature means that the device can sense changes on its ports and is able to react according to the pre-defined settings. Lightware Device Controller contains a user-friendly software tool and allows to create Events by defining a Condition and an Action.



Event Manager example

See more information about the settings in the Event Manager section.

## 3.10.2. Receiver Cloning - Configuration Backup and Restore



The receiver (configuration) cloning of HDMI-TPS-RX110AY is a simple method that eliminates the need to repeatedly configure certain devices to have identical (non-factory) settings. If the devices are installed in the same type of system multiple times then it is enough to set up only one device to fit the user's needs and then copy those settings to the others, thus saving time and resources.

See more information about the settings in the Configuration Cloning (Backup Tab) section.

# 3.10.3. Remote Firmware Upgrade of Connected Lightware Devices



The firmware of the Lightware TPS devices can be upgraded individually by Lightware Device Updater (LDU) software. HDMI-TPS-RX110AY contains a feature which allows having a faster and more comfortable firmware upgrade process. When the firmware of the connected extenders has to be upgraded the TPS connection is necessary towards the extenders – nothing else. The LDU will find the connected devices and can upgrade them.

The upgrade process is almost the same as in the case of the usual upgrade process. See the details of the process in the Remote Firmware Upgrade of Connected Lightware Devices section.

4. Operation HDMI-TPS-RX110AY – User's Manual 18



# Operation

This chapter is about the powering and operating of the device describing the functions which are available by the front/rear controls:

- **▶** FRONT PANEL SPECIAL FUNCTIONS
- SOFTWARE CONTROL MODES

# 4.1. Front Panel - Special Functions

# 4.1.1. Programmable Function Button



Action or an operation can be assigned to the **Function** button. "Function button pressed" is a condition that can be selected in the Event Manager. See more details in the Event Manager section.

# 4.1.2. Enable Dynamic (DHCP) IP Address



The device gets a static IP address as a factory default setting. If this setting does not fit to the circumstances during install or usage, DHCP can be enabled from the front panel:

- Step 1. Make sure the device is powered on and operational.
- **Step 2.** Press and keep pressed the **Function** button for 5 seconds.
- **Step 3.** After 5 seconds front panel LEDs start blinking; release the button and press it 3 times again quickly (within 3 seconds).
- Step 4. The LEDs get dark, DHCP gets enabled.

# 4.1.3. Reset to Factory Default Settings



To restore factory default values, do the following steps:

- Step 1. Make sure the device is powered on and operational.
- **Step 2.** Press and keep pressed the **Function** button for 10 seconds. After 5 seconds front panel LEDs start blinking but keep on pressing the button.
- **Step 3.** After 10 seconds the blinking gets faster; release the button and press it 3 times again quickly (within 3 seconds).
- **Step 4.** The LEDs get dark, the device restores the factory default settings and reboots.

Factory default settings are listed in the Factory Default Settings section.

# 4.1.4. Reseting the Device



In few cases (after firmware upgrade, etc) you may need to reset the device. Pushing the reset button results the same as you disconnect and reconnect the power adaptor to the receiver. To reseting the device follow the steps:

- Step 1. Push the button with a thin object for a second.
- **Step 2.** Wait until the device reboots. You can use the receiver when the LIVE LED is blinking slowly again.

**ATTENTION!** Reseting the device does not reset the settings to factory defaults. To reset factory default settings see previous section.

## 4.1.5. Entering Bootload Mode



It may happen that the firmware upgrade process is not successful as the device cannot be switched to bootload mode automatically. In this case, receiver device can be forced to switch to bootload mode as follows:

- **Step 1.** Make sure the transmitter is powered off.
- Step 2. Press and keep pressed the Function button.
- **Step 3.** Power on the receiver. If the device is switched to bootload mode the LIVE LED is blinking quickly (less than 500 ms duty cycle). The other LEDs are off.

# 4.2. Software Control Modes

User has more possibilities to control the device besides the front panel buttons. The following list contains the software control modes:

- Lightware Device Controller (LDC): you can connect to the device via our control software with using USB, RS-232 or Ethernet interfaces and control or configure the device as you wish. For the details see the Software Control - Lightware Device Controller chapter.
- LW2 protocol commands: you can configure the device by using the reduced command set of LW2 protocol. For more details see the LW2 Programmers' Reference chapter.
- LW3 protocol commands: you can configure the device by using the full-range command set of LW3 protocol. For more details see the LW3 Programmers' Reference chapter.

5. Software Control - Lightware Device Controller

HDMI-TPS-RX110AY - User's Manual



# **Software Control - Lightware Device Controller**

The device can be controlled by a computer through RS-232, Ethernet, and USB interfaces by the Lightware Device Controller (LDC). The software can be installed on a Windows PC or Mac OS X. The application and the User's Manual can be downloaded from www.lightware.com.

- ▶ INSTALL AND UPGRADE
- ESTABLISHING THE CONNECTION
- PORT PARAMETERS MENU
- DIAGNOSTIC TOOLS
- **▶** EDID MENU
- CONTROL MENU
- EVENT MANAGER
- SETTINGS MENU
- Configuration Cloning (Backup Tab)
- ADVANCED VIEW WINDOW

# 5.1. Install and Upgrade

INFO: After the installation, the Windows and the Mac application has the same look and functionality. This type of the installer is equal with the Normal install in case of Windows and results an updateable version with the same attributes.

#### Installation for Windows OS

Run the installer. If the User Account Control drops a pop-up message click **Yes** 

During the installation you will be prompted to select the type of the installation: **normal** and the **snapshot** install:

Normal install	Snapshot install	
Available for Windows and Mac OS X	Available for Windows	
The installer can update only this instance	Cannot be updated	
Only one updateable instance can exist	More than one different version	
for all users	can be installed for all users	

### Comparison of installation types

**ATTENTION!** Using the Normal install as the default choice is highly recommended.

#### Installation for Mac OS X

Mount the DMG file with double clicking on it and drag the LDC icon over the Applications icon to copy the program into the Applications folder. If you want to copy the LDC into another location just drag the icon over the desired folder.

Current version: 1.19.0b3

# **Upgrading of LDC**

Step 1. Run the application.

The **Device Discovery** window appears automatically and the program checks the available updates on Lightware's website and opens the update window if the LDC found updates.

The current and the update version number can be seen at the top of the window and they are shown in

this window even with the snapshot install.

The **Update** window can also be opened by clicking the **About icon** and the **Update** button.

**Step 2.** Set the desired update setting in the **Options** section.

- If you do not want to check for the updates automatically, uncheck the circle, which contains the green tick.
- If you want to postpone the update, a reminder can be set with different delays from the drop down list.




 If the proxy settings traverse the update process, set the proper values then click the **OK** button.

Step 3. Click the **Download update** button to start the upgrading.

The updates can be checked manually by clicking the **Check now** button.

# **5.2. Establishing the Connection**

- **Step 1.** Connect the device to a computer via USB, RS-232 or Ethernet.
- **Step 2.** Run the controller software; device discovery window appears automatically.



Device discovery window in LDC

# Change IP Address

To modify IP address settings quickly it is not necessary to enter the device's settings/network menu, you can set them by clicking the pencil icon beside the IP address.

You can see the new settings only in this window.



# Identifying the Device

Clicking on the icon results the blinking of the status LEDs for 10 seconds. The feature helps to identify the device itself in the rack shelf.



**Step 3.** Select the unit from the discovered Ethernet devices or under Serial devices; when the device is connected through RS-232 click on the **Query** button next to the desired serial port to display the device's name and serial number. Double click on the transmitter or select the device and click on the **Connect** button.



Serial devices tab in LDC

**ATTENTION!** Before the device is connected via the local RS-232 port, make sure that **Control mode** and **LW3 protocol** are set on the serial port.



USB tab in LDC

# 5.3. Port Parameters Menu

### 5.3.1. Video Tab



Video tab in Port parameters menu

The most important video related information and settings are available on this tab.

### Link Video (I1)

This is the TPS (HDBaseT) input line of the receiver. Clicking on the TPS icon results the settings panel appearing on the right side. You can check the status of the line, signal info and current emulated EDID.

### **Available Settings:**

- HDCP setting (enable / disable);
- TPS mode (see details in the TPS Interface section);
- Cable Diagnostics and Frame Detector tools;
- Reloading Factory Default Settings.


### **HDMI OUT Video (01)**

This is the HDMI output line of the receiver. Clicking on the HDMI icon results the settings panel appearing on the right side. You can check the status of the line, and signal and display info.

### **Available Settings:**

- Mute/Unmute port;
- Signal type: Auto, DVI, or HDMI;
- HDCP mode: Auto or Always;
- Power 5V mode: Auto, Always on, or Always off;
- Test pattern mode: Off, On, No signal;
- Test pattern clock source: 480p, 576p, or Original video signal;
- Test pattern: Red, Green, Blue, Black, White, Ramp, Chess, Bar, Cycle;
- Frame Detector;
- Reloading Factory Default Settings.

#### 5.3.2. Audio Tab



Audio tab in Port parameters menu

The most important audio related information and settings are available on this tab.

### Link Audio (I1)

This is the embedded TPS audio input line of the receiver. Clicking on the TPS icon results the settings panel appearing on the right side. You can check the signal info of the port.

21

### **Available Settings:**

- Mute/Unmute port;
- Lock/Unlock port;
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).

### **HDMI OUT Audio (01)**

This is the embedded HDMI audio output line of the receiver. Clicking on the HDMI icon results the settings panel appearing on the right side. You can check the signal info of the port.

### **Available Settings:**

- Mute/Unmute port;
- Lock/Unlock port;
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).

### Audio Out (02)

This is the de-embedded analog audio output line of the receiver. Clicking on the HDMI icon results the settings panel appearing on the right side. You can check the signal info and the de-embeding status of the signal.


### **Available Settings:**

- Mute/Unmute port;
- Volume (in percent);
- Balance;
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).

# 5.4. Diagnostic Tools

#### 5.4.1. Frame Detector

The ports can show detailed information about the signal like blanking intervals and active video resolution. This feature is a good troubleshooter if compatibility problems occur during system installation. To access this function, open the port properties window and click on **Frame detector** button.



Frame detector window


Lightware's Frame Detector function works like a signal analyzer and makes possible to determine the exact video format that is present on the port, thus helps to identify many problems. E.g. actual timing parameters may differ from the expected and this may cause some displays to drop the picture.

Frame Detector measures detailed timings on the video signals just like a built-in oscilloscope, but it is much more easy to use. Actual display area shows the active video size (light gray). Dark gray area of the full frame is the blanking interval which can contain the info frames and embedded audio data for HDMI signals. Shown values are measured actually on the signal and not retrieved only from the HDMI info frames.

# 5.4.2. Cable Diagnostics

The cable diagnostics is a useful tool to determine any cable related issues in case of TPS connection. The estimated cable length and the quality of the link are measured periodically and the diagnostic window shows the values in real-time. If the green bars hit the first line in the middle they turn into red. It means the number of the errors – during the extension – is higher than recommended. The link might be alive but recovering of the received data is not guaranteed.

INFO: Each bar represents a differential line in the CATx cable. The inappropriate termination of the cable usually causes high error rates. Check the cable terminations or change the cable.



#### Reference Values

Value	Explanation
10 <sup>-10</sup> -10 <sup>-9</sup>	Excellent image quality
10 <sup>-8</sup>	Minor error, not recognizable by eyes
10 <sup>-7</sup>	Sometimes recognizable flash on a special test pattern
10 <sup>-6</sup>	Small noise can be seen
10-5	Easy to recognize image error
10-4	Bad image quality

Above displayed "Video BER <  $10^{-10}$ " value means that on average there is 1 bad pixel after  $10^{10}$  pixels, which means the number of the bit errors is about 1 pixel in every 15 minutes.

INFO: You can find more details about maximum twisted pair cable distances in the Maximum Extension Distances section.

### **Table and Chart Views**

Cable diagnostics can be displayed in advanced modes as well. Two ways are available: **table view** and **chart view**. Data can be exported to a file on clicking on the **Export data** button.





Table view of cable diagnostics



Chart view of cable diagnostics

# 5.5. EDID Menu

Advanced EDID Management can be accessed by selecting the EDID menu. There are two panels: left one contains Source EDIDs, right one contains Destination places where the EDIDs can be emulated or copied.



#### EDID menu

#### **Control Buttons**



Exporting an EDID (save to a file)



Importing an EDID (load from a file)



Display EDID Summary window



Opening Advanced EDID Editor with the selected EDID



Opening Easy EDID Creator









Executing EDID emulation or copying (Transfer button)

Deleting EDID (from User memory)

Selecting all memory places in the right panel

Selecting none of the memory places in the right panel

## 5.5.1. EDID Operations

### **Changing Emulated EDID**

Step 1. Choose the desired EDID list on the source panel and select an EDID.



- Step 2. Press the Emulated button on the top of the Destination panel.
- Step 3. Select the desired port on the right panel (one or more ports can be selected); the EDID(s) will be highlighted with a yellow cursor.
- Step 4. Press the Transfer button to change the emulated EDID.

### Learning an EDID

The process is the same as changing the emulated EDID; the only difference is the Destination panel: press the **User** button. Thus, one or more EDIDs can be copied into the user memory either from the factory memory or from a connected sink (Dynamic).

### **Exporting an EDID**

ATTENTION! This function is working on Windows and Mac OS X operating systems and under Firefox or Chrome web browsers only.

Source EDID can be downloaded as a file (\*.bin, \*.dat or \*.edid) to the computer.



- Step 1. Select the desired EDID from the Source panel (line will be highlighted with yellow).
- Step 2. Press the Export button to open the dialog box and save the file to the computer.

## Importing an EDID

Previously saved EDID (\*.bin, \*.dat or \*.edid file) can be uploaded to the user memory:



- Step 1. Press the User button on the top of the Source panel and select a memory slot.
- Step 2. Press the Import button below the Source panel.
- Step 3. Browse the file in the opening window then press the Open button. Browsed EDID is imported into the selected User memory.

ATTENTION! The imported EDID overwrites the selected memory place even if it is not empty.

# Deleting EDID(s)

The EDID(s) from User memory can be deleted as follows:



- Step 1. Press User button on the top of the Destination panel.
- Step 2. Select the desired memory slot(s); one or more can be selected ("Select All" and "Select None" buttons can be used). The EDID(s) will be highlighted with yellow.
- **Step 3.** Press the **Delete selected** button to delete the EDID(s).

5. Software Control - Lightware Device Controller

HDMI-TPS-RX110AY - User's Manual 24

## 5.5.2. EDID Summary Window

Select an EDID from Source panel and press **Info** button to display EDID summary.






**EDID** summary window

# 5.5.3. Editing an EDID

Select an EDID from Source panel and press Edit button to display Advanced EDID Editor window. The editor can read and write all descriptors, which are defined in the standards, including the additional CEA extensions. Any EDID from the device's memory or a saved EDID file can be loaded into the editor. The software resolves the raw EDID and displays it as readable information to the user. All descriptors can be edited, and saved in an EDID file, or uploaded to the User memory. For more details about EDID Editor please visit our website (www.lightware.com) and download EDID Editor user's manual.



**EDID Editor window** 

# 5.5.4. Creating an EDID - Easy EDID Creator


Since above mentioned Advanced EDID Editor needs more complex knowledge about EDID, Lightware introduced a wizard-like interface for fast and easy EDID creation. With Easy EDID Creator it is possible to create custom EDIDs in four simple steps. By clicking on the Create button below Source panel, Easy EDID Creator is opened in a new window. For more details about EDID Editor please visit our website (www.lightware.com) and download EDID Editor user's manual.



**EDID Creator window** 

## 5.6. Control Menu

### 5.6.1. RS-232



RS-232 tab in Control menu


The following settings and functions are available (both on local and TPS serial ports):

- Operation mode: Pass-through, Control, or Command Injection (for more details about serial interface modes see the Serial Interface section);
- Baud rate: 4800, 7200, 9600, 14400, 19200, 38400, 57600, 115200;
- Data bits: 8 or 9;
- Parity: None, Odd, or Even;
- Stop bits: 1, 1.5, or 2;
- Command injection: enable or disable;
- Command injection port number;
- Control protocol: LW2 or LW3;
- Message sending via serial port;
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).

**ATTENTION!** Operation mode of the local and TPS serial ports can be set together only. It means if you set the local RS-232 port to Control mode, the TPS serial link will be changed to Control mode either automatically.

**ATTENTION!** If the receiver is connected to a TPS2 output board of a matrix frame, the RS-232 configuration settings (baud rate, data bits, e.t.c.) will not be changeable on the receiver side.

# 5.6.2. Relays




Relays tab in Control menu

Two relays are built into the HDMI-TPS-RX110AY receiver. The following settings are available for both relay ports:

- Connection state: Open or Close;
- Toggle;
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).

# 5.6.3. Ethernet



Ethernet tab in Control menu

Three ports are displayed in the Ethernet settings: Local, CPU, and TPS. You can check the status of the Ethernet line by each ports: the speed and the duplexity of the connection.

The following settings are available for each ports:

- Enable / disable the port; \*
- Reloading factory defaults (see factory default settings in the Factory Default Settings section).
- \* CPU Ethernet port cannot be disabled.


### 5.6.4. Infra

**ATTENTION!** The device has no built-in Infrared receiver and transmitter. For the complete usage attach an IR emitter unit to the IR OUT and an IR detector unit to the IR IN connectors.

Infrared (IR) receiver and transmitter options can be found on this tab. There are three submenus are available under it: IR codes, Ports, and Clear all IR codes.

### IR Codes

User can set the name of the IR code, the fingerprint (hash), and the repeat timeout in ms, as well as actions can be ordered to each IR codes.



IR codes window in Control menu

Description	Function	
ID	Code number.	
Name	You can give an unique name for the desired code.	
Fingerprint (hash) Fingerprint code in pronto hexa format.		
Detected	Indicator gives feedback about the given IR code is detected currently.	
Repeat timeout (ms)	You can set a timeout to avoid the involuntary code recurrence.	
Actions	Action buttons for the desired IR code: Save: saving the fingerprint. Cancel: canceling the fingerprint. Learn: learning the detected IR code.	
Detected IR fingerprints	You can check the detected IR codes in this panel. Pushing <b>Clear</b> button deleting all current fingerprints and switch on or off the automatic scrolling with the <b>Autoscroll</b> pipe.	


20 fingerprints can be stored in the device at the same time. Each of them can be ordered to an action in Event Manager. For more details about events see Event Manager section.

# **Learning IR Codes**

- **Step 1.** Connect the IR detector unit to the IR IN port of the receiver.
- Step 2. Click on the Learn button.
- **Step 3.** Turn the remote controller to the IR detector. A pop-up window appears in LDC press your remote button to learn.
- Step 4. Once the code is received, a new window pops up in LDC learning completed. Click OK to continue.
- **Step 5.** Optionally type a unique name for the code in the **Name** text box. The default name is code#, e.g. code0.

### **Ports**

User can set the name and command injection port to each sources and destinations. For more details about IR interface see the IR Interface section.



Infra tab - Ports window

### Clear all IR codes

Clicking on the button results deleting all stored IR fingerprints.

# 5.7. Event Manager

The feature means that the device can sense changes on its ports and able to react according to the pre-defined settings. The development idea of the Event manager is based on users' feedbacks. In many cases internal events (such as signal present or HDCP active) are necessary to display but it is not easy when the device is hard




to access (e.g. built under the desk). For more details and examples about Event Manager please visit our website (www.lightware.com) and download Event Manager user's guide in the Downloads section.

The Event manager can be configured to perform an action if a condition has been detected. E.g. the desired setup is that after a certain type of signal has been detected on I1 port, the port has to be switched to O1. The settings can be done via the LDC in the Control/Events tab, or by LW3 protocol commands. Configurable events number depends on the device what you are using actually.

Numerous new ideas and requests have been received in connection with the features and settings of the Event manager since the first release. Therefore, the user interface has been re-designed and many new functions implemented. The Event editor can be opened by pressing the Edit button at each Event.


There is a **gray bar** on the left of the Event panel in each line. If a condition and an action are set and the Event is enabled, the bar is displayed **in green**.



Control menu, Event Manager tab

#### 5.7.1. The Event Editor

Press the **Edit** button in the desired Event line to open the Event editor window.



The name of the Event is displayed. Type the desired name and press the Set name button. The Event can be cleared by the Clear button. Use the tick mark to enable/disable the Event.

Condition header

If the condition is set, the description (white colored text) and the exact LW3 protocol expression (yellow colored text) can be seen. If the advanced mode was used the description is "Custom condition".

Condition panel

The Wizard, the Advanced or the Link tool is available to set the condition.

The parameters and settings are displayed below the buttons.

4 Condition test The set condition can be tested to see the working method in the practice.

**Delay settings** The action can be scheduled to follow the condition after the set time value.

If the action is set, the description (white colored text) and the exact LW3 protocol expression (yellow colored text) can be seen. If the advanced mode was used the description is "Custom action".

**Action panel**The Wizard, the Advanced or the Link tool is available to set the action. The parameters and settings are displayed below the buttons.

8 Action test The set action can be tested to see the working method in the practice.

### 5.7.2. Create or Modify an Event

#### Wizard Mode

The wizard mode lists the most common conditions and actions, so the user does not have to look for LW3 nodes and properties.


- **Step 1.** Click on the **Edit** button of the desired Event; the **Event editor** is displayed.
- **Step 2.** The wizard mode is displayed as default. Select the desired **Category** first (e.g. Audio or Video).
- **Step 3.** Select the desired **Expression** from the drop-down menu. If any other parameter is necessary to set, it is going to be displayed.
- Step 4. Press the Apply button to store the settings of the Condition.



#### **Advanced Mode**

The goal of this mode is the same as of the wizard: set the properties and methods for conditions and actions. The difference is the number of the available and usable properties and methods of the LW3 protocol. Advanced mode allows almost all of it.

- **Step 1.** Click on the **Edit** button of the desired Event; the **Event editor** is displayed.
- **Step 2.** The wizard mode is the default, press the **Advanced** button. The LW3 protocol tree is displayed showing the list of the properties in the drop-down menu. Navigate to the desired node.
- **Step 3.** Select the desired **Property** from the menu. The manual of the property is displayed below to help to select the necessary property and to set the value.
- **Step 4.** Set the desired **value** and **operator**, then press the **Apply** button to store settings.



#### The Link Tool

The new interface allows creating more actions to the same condition. In that case, a condition can trigger more actions. To set such an Event, the Link tool has been introduced.

- **Step 1.** Click on the **Edit** button of the desired Event; the **Event editor** is displayed.
- **Step 2.** The wizard mode is displayed as default, press the **Link** button.
- Step 3. All the saved Events are analyzed and the conditions are listed (it takes some seconds to finish). The Show advanced expressions option allows showing the exact path and set the value of the given property.
- Empty condition
  Empty condition

  Wizard Advanced Link

  Show advanced expressions

  ID Event name Condition

  E1 Event1 Video signal is detected on I2
- Step 4. Select the desired Condition and press the Apply button to store the settings.

### 5.7.3. Special Tools and Accessories

#### The Name of the Event

The name of a port can be changed by typing the new name and clicking the **Set** button. The following characters are allowed when naming:

Letters (A-Z) and (a-z), numbers (0-9), special characters: hyphen (-), underscore ( $_-$ ), and space ().

#### **Enable or Disable an Event**

The set Event can be enabled or disabled in the Event list, or directly in the Event editor window by setting the **tick mark** beside the name.

### **Testing the Condition**

When the desired Condition is arranged, the setting can be tested. The Event list and the Event editor contains a small panel that shows if the set condition is detected and how many times. The **Counter** can be reset by the button in Event editor. If the Condition is true, the **detected** mark turns green for two seconds and the **Counter** is increased.

### **Testing the Action**


The method is the same as testing the Condition, but in this case, the Action can be triggered manually by pressing the **Test** button.

TIPS AND TRICKS: The Test button is also placed on the Action panel in the Event list. Thus, you can check the Actions without opening the Event editor.

# **Delay the Action**

In most cases the Action is performed immediately after the Condition is detected. But sometimes a delay is necessary between the Condition and the Action. Therefore, the new Event manager contains the Delay panel which allows that feature with below settings:

- No delay: when the Condition is detected, the Action is launched.
- **Simple delay**: when the Condition is detected, the Action is launched after the set time interval.
- **Still exists**: when the Condition is detected, the Action is launched after the set time interval only if the Condition still exists.
- Continuously exists: when the Condition is detected, the Action is launched after the set time interval only if the Condition has been existing continuously.



### The available delay settings of an Event

TIPS AND TRICKS: **Show advanced expressions** option is a useful tool when you look for the path or value of a property but just the expression is displayed. The option is available in the Event list window or when Link tool is used.

## 5.7.4. Clear One or More Event(s)

#### Clear an Event

Press the **Clear** button in the Event list or in the header section in the Event editor.

#### Clear all Events

When all the Events must be cleared press the **Load factory defaults** button above the Event list. You will be prompted to confirm the process.

# 5.7.5. Export and Import Events

The feature allows saving all the Events. The backup file can be uploaded to another HDMI-TPS-RX110AY receiver.

# **Export all the Events**

- Step 1. Press the Export button above the Event list.
- **Step 2.** The Save as dialog box will appear. Set the desired folder and file name, then press the **Save** button.

The generated file is a simple text file which contains LW3 protocol commands. The file can be viewed by a simple text editor, e.g. Notepad.

**ATTENTION!** Editing the file is recommended only for expert users.

#### Import all the Events

- Step 1. Press the Import button above the Event list.
- **Step 2.** The Open dialog box will appear. Select the desired folder and file, then press the **Open** button.


### 5.7.6. Event Creating - Example

The following example shows you on a real-life situation how to set up an Event.

### **The Concept**

The HDMI-TPS-RX110AY receiver is connected to a projector by the HDMI output port. The receiver is also connected to the projector by the RS-232 port and can send commands via the serial line.

The task is to turn on the projector when signal is detected on the HDMI output port.



# **RS-232 Settings**

Make sure that the serial line is established between the receiver and the projector. Check that the RS-232 settings of the receiver is set exactly the same which required for the projector: baud rate, data bits, parity, stop bits. The receiver needs to be set to: Control protocol: LW3; and RS-232 mode: Pass-through. See the relevant LDC settings in the RS-232 section.

### **Setting the Event**

You can create the Event in the Wizard in few simple steps:

Step 1. Set the condition.

Select the required parameters to set the condition:

- Category: Video:
- **Expression**: Signal is detected on a port:
- Port: 01.

Click on the **Apply** button to complete the procedure. When it is done, the condition appears on the upper side in textual and LW3 command format as well.

Step 2. Set the action.

If the condition is fulfilled, the following action needs to be launched: the receiver sends a command to the projector over the serial line:

• Power on - the required command which is accepted by the projector: PWR0<CR><LF>

For this instance the command has to be closed with the <CR><LF> characters so they need to be escaped. You can use the following format for escaping:

<command<sub>2</sub>><\x0d\x0a><command<sub>2</sub>><\x0d\x0a>... ...<command\_><\x0d\x0a>

In the current case the command is: PWR0\x0d\x0a

Select the required parameters to set the action:

Category: RS-232;

Expression: Send RS-232 message;


Port: P1;


Message: PWR0\x0d\x0a


Step 3. Enable the Event.

Select the E1 enabled pipe in upper left corner to set the Event as launched.

INFO: If you do not find the required category/expression/etc what you need, choose the Advanced mode in the Wizard where the entire LW3 structure tree is available. For example instead of signal detection you can set a specified resolution or color range either as a condition.








# 5.8. Settings Menu

### 5.8.1. Status



31

Status tab in Settings menu


The most important hardware and software related information can be found on this tab: hardware and firmware version, serial numbers, temperatures, operation time, and voltage information. Device label can be changed to unique description by the Set button.

You can disable the Function button functionally with marking the **Button lock** option.

Clicking on the **Identify me** button results the blinking of the status (in green) and crosspoint LEDs (in orange) for 10 seconds. The feature helps to identify the device itself in the rack shelf.



## 5.8.2. Network




Network tab in Settings menu

IP address and DHCP settings can be set on this tab. Always press the **Apply settings** button to save changes. Factory defaults settings can be recalled with a dedicated button.

# 5.8.3. Backup

Details about this function can be found in the Configuration Cloning (Backup Tab) section.

# 5.8.4. System




32

System tab in Settings menu

Three functions are available under System tab:

- Download system log saving the file of the device.
- Load factory defaults recalling factory defaults settings and values. All factory default settings are listed in the Factory Default Settings section.
- **Reboot** rebooting the system.

# 5.9. Configuration Cloning (Backup Tab)



Backup tab

The configuration cloning of Lightware LW3 devices is a simple method that eliminates the need to repeatedly configure certain devices to have identical (non-factory) settings. If the devices are installed in the same type of system multiple times then it is enough to set up only one device to fit the user's needs and then copy those settings to the others, thus saving time and resources.

# 5.9.1. Cloning Steps in a Nutshell

Installing multiple devices with the same customized configuration settings can be done in a few easy steps:

- Step 1. Configure one device with all your desired settings with the LDC software.
- Step 2. Backup the full configuration file to your computer.
- **Step 3.** If needed, make some modifications to the configuration file using a text editor (e.g. Notepad). E.g. modifying the static IP address is needed when DHCP is not used.
- Step 4. Connect to the other device which has to be configured and upload (restore) your configuration file.
- Step 5. Done! You can have as many totally identical, customized devices as you like.

### 5.9.2. Save the Settings of the Device (Backup)

- **Step 1.** Apply the desired settings in the transmitter (port parameters, crosspoint, etc.)
- Step 2. Select the Settings / Backup tab from the menu.
- **Step 3.** Write a short **description** in the text box on the left (optional).
- **Step 4.** Press the **Create a full backup** button. You will be prompted to save the file to the computer. The default file name is the following:

Step 5. Set the desired file name, select the folder and save the file.

TIPS AND TRICKS: Using the exact product type in the filename is recommended since it makes the file usage more comfortable.

### **About the Backup File**

The backup file is a simple text file which contains LW3 protocol commands. The first line is the description, and the further lines are the commands which will be executed during the restore process. The file can be viewed (and/or edited) by a simple text editor, e.g. Notepad.

**ATTENTION!** Editing the command lines is only recommended for expert users.

### See the entire list of saved data in the section.

# 5.9.3. Upload the Settings to a Device (Restore)

WARNING!: Please note that the settings will be permanently overwritten with the restored parameters in the device. Withdrawal is not possible.

**ATTENTION!**: The cloning is successful when the backup file is downloaded from the same type of source device as the destination device.

## **The Restoring Process**

- Step 1. Select the Settings / Backup tab from the menu.
- Step 2. Click on the Choose file button on the right panel and browse the desired file.
- **Step 3.** The file is checked and the result will be displayed in the textbox below. If the file is correct, the settings can be restored.
- **Step 4.** Choose **IP settings** what you want to use after backup. You can apply settings from the backup file, keep actual settings, set it manually in a dialog box or apply DHCP.
- Step 5. Press the Start restore process button and click on the Yes button when asked.
- Step 6. Reboot the device to apply the network settings after finishing.

5. Software Control - Lightware Device Controller

HDMI-TPS-RX110AY - User's Manual

# 5.9.4. Create and Restore Backups from the Device Memory

HDMI-TPS-RX110AY receiver is able to store backups in its own memory and can be recalled from there so user does not need to save backup files to the local computer. Four slots are available for this purpose.



You can save presets as not protected with using **Save** button and as protected with using the **Save as protected** button. Restoring a preset select on the slot of the desired backup and click on the **Apply** button. You can save presets from a file from your local computer clicking on the **Upload** button and you can also save a preset from the device's memory to a backup file with using the **Download** button. If you do not need a saved preset any more, select it and click on the **Delete** button.

WARNING! Loading factory default settings will erase all presets which has been saved in the device memory!

# 5.10. Advanced View Window

Terminal window



1 LW3 protocol help Pushing the button results a help window opening which describes the most important information about LW3 protocol commands in HTML format.

**Edit mode**The default appearance is the read-only mode. If you want to modify the values or parameters, tick the option. You will be prompted to confirm your selection.

**Warning mode** If this pipe checked in, a warning window pops up when you enable Edit mode.

Commands and responses with time and date are listed in this window. Sent command starts with '>' character, received response starts with '<' character. The color of each item depends on the type of the command and response. The content of the window can be emptied by the **Clear** button. If the **Autoscroll** option is ticked, the list is scrolled automatically when a new line is added.

Type the desired command and execute it by the **Send** button. Clear all current commands and responses in the Terminal window by the **Clear** button.

Protocol tree LW3 protocol tree; select an item to see its content.

**Node list**Correspondent parameters and nodes are shown which are connected to the selected item in the protocol tree.

Manual button: Manual (short description) of the node can be called and

displayed in the terminal window.

**Set** button: Saves the value/parameter typed in the textbox.

**Call** button: Calls the method, e.g. reloads factory default settings.

6. LW2 Programmers' Reference HDMI-TPS-RX110AY – User's Manual 35



# **LW2 Programmers' Reference**

The device can be controlled through a reduced command set of LW2 protocol commands to ensure the compatibility with other Lightware products. The supported LW2 commands are described in this chapter.

- **▶** LW2 PROTOCOL DESCRIPTION
- ▶ GENERAL LW2 COMMANDS
- ▶ PORT SETTINGS
- **▶** NETWORK CONFIGURATION
- ▶ RS-232 SETTINGS
- **▶** RELAY SETTINGS
- ► LW2 COMMANDS QUICK SUMMARY

# 6.1. LW2 Protocol Description

The device accepts commands surrounded by curly brackets - { } - and responds data surrounded by round brackets - ( ) - only if a command was successfully executed.

Format	Explanation
<in></in>	Input number in 1 or 2 digit ASCII format (01, 5, 07, 16, etc.)
<out></out>	Output number in 1 or 2 digit ASCII format
<in²></in²>	Input number in 2 digit ASCII format (01, 02, 10, 12 etc.)
<out²></out²>	Output number in 2 digit ASCII format (01, 02, 10, 12 etc.)
<loc></loc>	Location number in 1, 2 or 3 digit ASCII format
<id></id>	id number in 1 or 2 digit ASCII format
<id²></id²>	id number in 2 digit ASCII format
CrLf	Carriage return, Line feed (0x0D, 0x0A)
•	Space character (0x20)
<b>→</b>	Each command issued by the controller
<b>—</b>	Each response received from the router

# 6.2. General LW2 Commands

# 6.2.1. View Product Type

**Description**: The device responds its name.

Format	Example
Command {I}	→ {i}
Response (I: <product_type>)CrLf</product_type>	← (I:HDMI-TPS-RX110AY)

**Explanation**: The connected device is a HDMI-TPS-RX110AY.

Legend: <PRODUCT\_TYPE> shows type.

# 6.2.2. Query Control Protocol

**Description**: The device can be controlled with different control protocols. This command queries the active protocol of the currently used control interface.

Format	Example
Command {P_?} Response (CURRENT●PROTOCOL●=●# <pre>#<pre>protocol&gt;) CrLf</pre></pre>	→ {P_?} ← (CURRENT PROTOCOL = #1)

**Explanation**: The device communicates with LW2 protocol.

6. LW2 Programmers' Reference HDMI-TPS-RX110AY – User's Manual

### 6.2.3. View Firmware Version of the CPU

**Description**: View the CPU firmware revision.

Format	Example
Command {F} Response (FW: <fw_ver><s>)CrLf</s></fw_ver>	→ {f} ← (FW:1.2.0b6)

Legend: <FW\_VER> is the firmware version. It is followed by <s> string which may indicate special versions.

## 6.2.4. Connection Test

**Description**: Simple test to see if the connection is established successfully.

Format	Example
Command {PING} Response (PONG!)CrLf	→ {ping} ← (PONG!)

### 6.2.5. View Serial Number

**Description**: The device responds its 8-digit serial number.

Format	Example
Command {S}	$\rightarrow$ {s}
Response (SN: <serial_n>)CrLf</serial_n>	← (SN:5A004254)

# 6.2.6. Compile Time

**Description**: Returns the date, when the CPU firmware was compiled.

Format	Example
Command (CT)	→ {ct}
Response (Complied: <date&time>)CrLf</date&time>	← (Compiled: Sep 30 2016 14:07:56)

### 6.2.7. View Installed Board

**Description**: Shows the hardware name and revision of the installed cards.

Format	Example
Command {IS} Response (SL#●0● <mb_desc>)CrLf (SL●END)CrLf</mb_desc>	→ {is} ← (SL# 0 HDMI-TPS-RX110AY V12) ← (SL END)

**Explanation**: The device reports its motherboard (slot 0).

### 6.2.8. View Firmware for All Controllers

**Description**: Shows the firmware versions of all installed controllers.

Format	Example
Command {FC} Response (CF● <desc>)CrLf (CF●<desc>)CrLf</desc></desc>	→ {fc} ← (CF HDMI-TPS-RX110AY 1.2.0b6)
 (CF END)CrLf	← (SL END)

**Explanation**: The device has one control panel.

### 6.2.9. Restart the Device

**Description**: The device can be restarted without unplugging power.

Format	Example
Command {RST} Response	→ {RST}

**Explanation**: The device reboots; no response is sent in this case.

# 6.2.10. Query Health Status

**Description:** Internal voltages and measured temperature values are shown.

Format	Example
Command {ST} Response (ST• <desc>)CrLf</desc>	→ {ST} ← (ST CPU 0.09V 12.13V 5.03V 3.31V 3.32V 3.39V 1.85V 1.31V 1.00V 42.46C 42.55C)

# 6.2.11. Restore Factory Default Settings

**Description**: Settings can be reset to factory default values as follows:

Format	Example
Command {FACTORY=ALL} Response (FACTORY ALL)CrLf	→ {factory=all} ← (FACTORY ALL)

**Explanation**: All settings and parameters are reset to factory default, see the table in the Factory Default Settings section.

## 6.3. Port Settings

## 6.3.1. Mute Specified Output

INFO: <A/V/AV> option usually can be skipped for legacy purposes. In this case, the devices change all (Video & Audio) layers but using status commands it displays information about only the Video layer. Please use AV option, when available.

**Description**: Mute output <out>. The output signal is turned off.

Format	Example
Command {# <out>•<layer>} Response (1MT<out²>•<layer>)CrLf</layer></out²></layer></out>	→ {#1 AV} ← (1MT01 AV)

**Explanation**: 01 audio and 01 video output ports are muted.

Legend:

<layer></layer>	Layer
Α	Audio layer
V	Video layer
AV (or nothing)	Audio & Video layer

**ATTENTION!** Muting does not change the crosspoint's state but disables the output itself. This way the last connection can be easily restored with an unmute command. Switching a muted output does not unmute the output.

## 6.3.2. Unmute Specified Output

**Description**: Unmute output <out>.

Format	Example
Command {+ <out>•<layer>}</layer></out>	→ {+2 A}
Response (0MT <out²>•<layer>)CrLf</layer></out²>	← (0MT02 A)

Explanation: O2 audio port is unmuted.

**Legend**: See in the previous section.

INFO: Unmuting an output makes the previous connection active as the crosspoint state has not been changed by the muting command, only the output was disabled.

## 6.3.3. Lock the Output

Description: Lock an output port. Output's state cannot be changed until unlocking.

Format	Example
Command {#> <out>•<layer>}</layer></out>	→ {#>1 AV}
Response (1LO <out²>•<layer>)CrLf</layer></out²>	← (1L001 AV)

Explanation: O1 audio port and O1 video output ports are locked.

**Legend**: See in the Mute Specified Output section.

## 6.3.4. Unlock the Output

**Description**: Unlock an output port. The connection on output can be changed.

Format	Example
Command {+< <out>•<layer>} Response (0LO<out²>•<layer>)CrLf</layer></out²></layer></out>	→ {+<1 A} ← (0L001 A)

Explanation: 01 audio output port is unlocked.

Legend: See in the Mute Specified Output section.

INFO: The device issues the above response regardless of the previous state of the output (either it was locked or unlocked).

## 6.3.5. View Connection State on The Output

**Description**: Viewing the crosspoint state of the device; showing the input port numbers connected to the outputs.

Format	Example
Command {VC• <layer>} Response (ALL<layer>•&lt;001&gt;•&lt;002&gt;)CrLf</layer></layer>	→ {vc av} ← (ALLV 01 01) ← (ALLA 01 01)

**Legend**: All <0x> indexes show the corresponding output's connection state. If value <02> equals 01 it means that output 2 is connected to input 1. All <0x> indexes are two digit ASCII characters (01 or 02).

#### State Letters:

Letter	State	Example
L	Output is locked	L01
М	Output is muted	M01
U	Output is locked and muted	U01

**Explanation**: O1 audio and O1 video output ports are connected to I1 audio and I1 video input ports.

## 6.3.6. View Crosspoint Size

**Description**: Shows the physical crosspoint size.

Format	Example
Command {GETSIZE● <layer>} Response (SIZE=<size>●<layer>)CrLf</layer></size></layer>	→ {getsize av} ← (SIZE=1x1 V) ← (SIZE=1x2 A)

**Legend**: <size>: <number of inputs>x<number of outputs>

<layer>: See the details in the Mute Specified Output section.

**Explanation**: The device reports that it has a video crosspoint with 1 input and 1 output, and an audio crosspoint with 1 input and 2 outputs.

## 6.4. Network Configuration

## 6.4.1. Query the Current IP Status

**Description**: IP address settings can be queried as follows.

Format	Example
Command {IP_STAT=?} Response (IP_STAT= <type>;</type>	→ {ip_stat=?} ← (IP_STAT=0;192.168.0.100; 255.255.255.0;192.168.0.1)

**Legend**:  $\langle type \rangle$ : 0 = static IP; 1 = DHCP.

<ip\_addr>:
IP address (four decimal octets separated by

dots).

<subnet\_mask>: Subnet mask (four decimal octets separated by

dots).

<gateway\_addr>: Gateway address (four decimal octets separated

by dots).

**Explanation**: The device has a static (fix) IP address: 192.168.0.95; the subnet mask is 255.255.255.0, the gateway address is 192.168.0.1.

#### 6.4.2. Set the IP Address

**Description**: IP address can be set as follows.

Format	Example
Command {IP_ADDRESS= <type>;<ip_address>} Response (IP_ADDRESS=<type>;<ip_address>)CrLf</ip_address></type></ip_address></type>	→ {ip_address=0;192.168.0.110} ← (IP_ADDRESS=0;192.168.0.110;)

**Legend**: <type>: 0 = static IP; 1 = DHCP

INFO: The IP address can be queried by typing the "ip\_address=?" command. The response contains the fix IP address that is stored in the device even if DHCP is enabled; in this case, this IP address is not valid.

#### 6.4.3. Set the Subnet Mask

**Description**: Subnet mask can be set as follows.

Format	Example
Command {IP_NETMASK= <subnet_mask>} Response (IP_NETMASK=<subnet_mask>)CrLf</subnet_mask></subnet_mask>	→ {ip_netmask=255.255.255.0} ← (IP_NETMASK=255.255.255.0)

**Legend**: <subnet\_mask>: Four decimal octets separated by dots.

INFO: The subnet mask can be queried by typing the "ip\_address=?" command. The response contains the fix IP subnet mask that is stored in the device even if DHCP is enabled; in this case, this IP subnet mask is not valid.

## 6.4.4. Set the Gateway Address

**Description**: Gateway address can be set as follows.

Format	Example
	→ {ip_gateway=192.168.0.50} ← (IP_GATEWAY=192.168.0.50)

**Legend**: <gateway\_addr>: Four decimal octets separated by dots.

INFO: The gateway address can be queried by typing the "ip\_gateway=?" command. The response contains the static IP gateway address that is stored in the device even if DHCP is enabled. In that case, the latest valid gateway address (for static IP) is stored.

## 6.4.5. Apply Network Settings

**Description**: Apply the network settings and restart the network interface.

Format	Example
Command {ip_apply} Response (IP_APPLY)CrLf	→ {ip_apply} ← (IP_APPLY)

## 6.5. RS-232 settings

#### 6.5.1. Set RS-232 Mode

**Description**: RS-232 mode can be set as follows. See more details about RS-232 modes in the Serial Interface section.

Format	Example
Command {RS232= <mode>}</mode>	→ {RS232=CONTROL}
Response (RS232= <mode>)CrLf</mode>	← (RS232=CONTROL)

Legend:

<mode>:

CONTROL = Control mode;

CI = Command Injection mode;

PASS = Pass-through.

#### 6.5.2. Set Local RS-232 Parameters

**Description**: The parameters of local RS-232 port can be set as follows.

Format	Example
Command {RS232_LOCAL_FORMAT=	→ {RS232_LOCAL_FORMAT=9600;9;0;X}
Response (RS232_LOCAL_FORMAT=	← (RS232_LOCAL_FORMAT=9600;9;0;1)

#### Legend:

<parameter></parameter>	Parameter	Values
<baudrate></baudrate>	Baud rate	X (no change); 4800; 7200, 9600; 14400; 19200; 38400; 57600; 115200
<databit></databit>	Data bit	X (no change); 8; 9
<parity></parity>	Parity	X (no change); N (None); E (Even); O (Odd)
<stopbit></stopbit>	Stop bit	X (no change); 1; 1,5; 2

**Explanation**: Local RS-232 port is set the baud rate to 9600, data bit to 9, parity to odd, and stop bit is not changed, remained 1.

INFO: The current settings can be queried by the "RS232\_LOCAL\_FORMAT=?" command.

#### 6.5.3. Set Link RS-232 Parameters

**Description**: The parameters of RS-232 TPS link port can be set as follows.

Format	Example
Command {RS232_LINK_FORMAT= <baudrate>;</baudrate>	→ {RS232_LINK_FORMAT=9600;9;0;X}
<databit>;<parity>;<stopbit>}</stopbit></parity></databit>	
Response (RS232_LINK_FORMAT= <baudrate>;</baudrate>	← (RS232_LINK_FORMAT=9600;9;0;1)
<databit>;<parity>;<stopbit>)CrLf</stopbit></parity></databit>	

**Legend**: see previous section.

**Explanation**: RS-232 TPS link port is set the baud rate to 9600, data bit to 9, parity to odd, and stop bit is not changed, remained 1.

INFO: The current settings can be queried by the "RS232\_LINK\_FORMAT=?" command.

#### 6.5.4. Set Local RS-232 Control Protocol Port

**Description**: The control protocol of local RS-232 port can be set as follows.

Format	Example
Command {RS232_LOCAL_PROT= <protocol>} Response (RS232_LOCAL_PROT=<protocol>)CrLf</protocol></protocol>	→ {RS232_LOCAL_PROT=LW2} ← (RS232_LOCAL_PROT=LW2)

Legend:

LW2 = LW2 command protocol

LW3 = LW3 command protocol

INFO: The current setting can be queried by the "RS232\_LOCAL\_PROT=?" command.

#### 6.5.5. Set Link RS-232 Control Protocol Port

Description: The port number of RS-232 TPS link port can be set as follows.

Format	Example
Command {RS232_LINK_PROT= <protocol>} Response (RS232_LINK_PROT=<protocol>)CrLf</protocol></protocol>	→ {RS232_LINK_PROT=LW2} ← (RS232_LINK_PROT=LW2)

Legend:

LW2 = LW2 command protocol

LW3 = LW3 command protocol

INFO: The current setting can be queried by the "RS232\_LINK\_PROT=?" command.

# 6.6. Relay Settings

## 6.6.1. Query Relay Connection State

**Description**: Current relay connection state can be queried.

Format	Example
Command {RELAY <port_nr>=?} Response (RELAY<port_nr>=<dir>;<state>)CrLf</state></dir></port_nr></port_nr>	→ {RELAY1=?} ← (RELAY1=0;0)

**Legend**: <dir>: it is always 0.

<state>:

Parameter	Description
С	Closed
0	Opened

Explanation: Relay1 is opened now.

## 6.6.2. Set Relay Connection State

**Description**: Relay connection state can be changed to be opened or closed.

	Format	Example
- 1		→ {RELAY1=0;C} ← (RELAY1=0;C)

**Legend**: <dir>: it is always 0.

<state>:

Parameter	Description
С	Closed
0	Opened

**Explanation**: Relay1 is closed now.

# 6.7. LW2 Commands - Quick Summary

## **General LW2 Commands**

Operation	See in chapter	Command
View Product Type	6.2.1	{1}
Query Control Protocol	6.2.2	{P_?}
View Firmware Version of the CPU	6.2.3	{F}
Connection Test	6.2.4	{PING}
View Serial Number	6.2.5	{S}
Compile Time	6.2.6	{CT}
View Installed Board	6.2.7	{IS}
View Firmware for All Controllers	6.2.8	{FC}
Restart the Device	6.2.9	{RST}
Query Health Status	6.2.10	{ST}
Restore Factory Default Settings	6.2.11	{FACTORY=ALL}

## **Port and Crosspoint Settings**

Operation	See in chapter	Command
Mute Specified Output	6.3.1	{# <out>•<layer>}</layer></out>
Unmute Specified Output	6.3.2	{+ <out>•<layer>}</layer></out>
Lock the Output	6.3.3	{#> <out>•<layer>}</layer></out>
Unlock the Output	6.3.4	{+ <out>•<layer>}</layer></out>
View Connection State on The Output	6.3.5	{VC• <layer>}</layer>
View Crosspoint Size	6.3.6	{GETSIZE• <layer>}</layer>

## **Network Configuration**

Operation	See in chapter	Command
Query the Current IP Status	6.4.1	{IP_STAT=?}
Set the IP Address	6.4.2	{IP_ADDRESS= <type>;IP_ADDRESS}</type>
Set the Subnet Mask	6.4.3	{IP_NETMASK= <subnet_mask>}</subnet_mask>
Set the Gateway Address	6.4.4	{IP_GATEWAY= <gateway_address>}</gateway_address>
Apply Network Settings	6.4.5	{IP_APPLY}

## **RS-232 Settings**

Operation	See in chapter	Command
Set RS-232 Mode	6.5.1	{RS232= <mode>}</mode>
Set Local RS-232 Parameters	6.5.2	{RS232_LOCAL_FORMAT= <baudrate>;<databit>;<parity>;<stopbit>}</stopbit></parity></databit></baudrate>
Set Link RS-232 Parameters	6.5.3	{RS232_LINK_FORMAT= <baudrate>;<databit>;<parity>;<stopbit>}</stopbit></parity></databit></baudrate>
Set Local RS-232 Control Protocol Port	6.5.4	RS232_LOCAL_PROT= <pre>rotocol&gt;</pre>
Set Link RS-232 Control Protocol Port	6.5.5	RS232_LINK_PROT= <protocol></protocol>

## **Relay Settings**

Operation	See in chapter	Command
Query Relay Connection State	6.6.1	{RELAY <port_nr>=?}</port_nr>
Set Relay Connection State	6.6.2	{RELAY <port_nr>=0;0 C}</port_nr>



# **LW3 Programmers' Reference**

The device can be controlled through Lightware 3 (LW3) protocol commands to ensure the compatibility with other Lightware products. The supported LW3 commands are described in this chapter

- OVERVIEW
- ▶ THE TREE STRUCTURE OF THE RECEIVER
- ► LW3 COMMANDS
- **▶** FORMAL DEFINITIONS
- SYSTEM COMMANDS
- VIDEO PORT SETTINGS
- Audio Port Settings
- ► NETWORK CONFIGURATION
- ▶ RS-232 PORT CONFIGURATION
- Sending Message via the Communication Ports
- Infrared Port Configuration
- RELAY PORT SETTINGS
- **▶** EDID MANAGEMENT
- **▶** LW3 Commands Quick Summary

## 7.1. Overview

Lightware 3 (LW3) protocol is used by the 25G hybrid matrix, the MODEX family and the new series of Lightware TPS and OPT products, including the HDMI-TPS-RX110AY receiver. The protocol (LW3) is ASCII-based and all commands are terminated with a carriage return (Cr, '\r') and line feed (Lf, '\n') pair. It is organized as a tree structure that provides outstanding flexibility for implementing a human readable, but programmatically still ease to parse, which is suitable for different products with a different feature list.

In order to implement a flexible, easy-to-use protocol that is straightforward to adapt to new devices and provides outstanding scalability and sustainability, we decided to organize all settings, parameters and properties of the device to a tree structure with 'nodes', 'properties' and 'methods'.

#### 7.1.1. Elements of the Tree Structure

**ATTENTION!** All names and values are case-sensitive. The space character is replaced by the '•' character in the elements and commands descriptions.

#### 7.1.1.1. Node

- The basic building block of the tree structure is the 'node'.
- The node can have multiple child nodes, but only one parent.
- The tree has only one root the 'root node'.
- The leaves of the tree are also nodes, which do not have child nodes.
- The nodes are separated by a slash ('/') character.
- All the slashes are 'right slashes', no backslash is used.
- The identifier of the root node is a slash ('/')
- The node name can contain the elements of the English alphabet and numbers.
- Recommended convention for case sensitivity:
  - Fix nodes (that cannot be altered) are capitalized.
  - User created nodes can contain both lowercase and capital letters, no restrictions.
- The path of a node has to contain all parent nodes from the root node.

Format: (the root node): nX●/


Path: nX•/[nodeName]/[nodeName]/

#### Legend:

n:	node
'X' can be:	
<i>'</i> 2:	default for a node.
'm':	this is a manual for the node.
'E':	this is an error message for the node.
's':	this is a symlink node.
'v':	this node has virtual children.
'r':	this is a remote node.

INFO: All parent nodes must be listed in the path of a node.

Following example presents the structure of the tree traversal:



#### Path of the nodes:

n-/node1

n-/node1/node11

n-/node1/node12

n-/node2

n-/node2/node21

n-/node2/node21/node211

n-/node3

Tree structure of the nodes

## 7.1.1.2. Property

The 'property' in the LW3 protocol is basically a leaf, which has a well-defined value.

- A property has a value.
- A property cannot have child nodes or child properties. It is always a leaf.
- A node can have any number of properties (may not have any).
- A property is referenced with a dot ('.') after the node name.
- The properties' name can contain the elements of the English alphabet, numbers and underscore ('\_')
  character.
- By convention, properties are beginning with a capital letter, all other characters are lowercase ones.
   In the case of compound words, all words are beginning with a capital letter (CamelCase).
- The value of the property can contain any readable ASCII character.
- A property can be read-only or read/write.

Format: pX●/[nodeName].[propertyName]=[propertyValue]

## Legend:

p: property

'X' can be:

'r': if the property is read-only.

'w': if the property is readable, writable.

'm': the manual of the property.

E': error message for the property.

'v': virtual node property: contains a node path to a node which will be linked to the property's parent node.

#### Example:

The following two ones are read-only properties:

pr●/node1/node12.ReadOnlyProperty=value1

pr●/.DeviceName=25G Hybrid Device

The following two ones are read-write properties:

pw•/node1/node12.ReadWriteProperty=value2

pw•/.DeviceNickName=John

#### 7.1.1.3. Method

The 'method' in the LW3 protocol is also a leaf. It cannot have a value, such as the properties, but it can be invoked with a parameter with the help of a special 'CALL' command.

- A method cannot have child nodes or child methods. It is always a leaf.
- A node can have any number of methods (may not have any).
- A method is referenced with a colon (':') after the node.
- The methods' name can contain the elements of the English alphabet, numbers and underscore ('\_')
  character.
- By convention, methods are beginning with lowercase letter. In case of compound words, the very first letter is lowercase, and the first letter of each other words are capitalized (lowerCamelCase).
- The parameter of the method can contain any readable ASCII character.
- The method always has a return 'state' if the method could be executed. The state could be either 'OK' or 'FAILED'.
- The method does not necessarily have a return 'value'. If it does, it can contain additional information, which is always specific to the current case (the return value can specify why the execution failed).
- When the method cannot be executed (e.g. the parameter list is illegal), there is an error message.

Format: mX•/[nodeName]:[methodName]=[returnValue]

## Legend:

m: method

'X' can be:

'O': when the execution of the method was successful (OK).

'F': when the execution of the method failed

'm': the manual of the method.

'E': error message for the method.

#### Example:

mO•/node1/node12:method1

mO•/MEDIA/VIDEO/XP:switch

mm

/MEDIA/VIDEO/XP:lockSource:Lock one or more source ports

## 7.1.2. Escaping

Property values and method parameters can contain characters that are used as control characters in the protocol. They must be escaped. The escape character is the backslash ('\') and escaping means injecting a backslash before the character that should be escaped (like in C language).

Control characters are the followings: \ { } # % ( ) \r \n \t

#### Example:

The original text: John

(Doe).

#3:

5%2=1

node1\node11

The escaped text:  $John \cdot (Doe \cdot). \cdot \#3: \bullet 5 \cdot \%2 = 1 \bullet node 1 \cdot node 11$ 

## 7.1.3. Error Messages

There are several error messages defined in the LW3 protocol, all of them have a unique error number.

Format: XE•[primitive]•%EYYY:•[Error message]

## Legend:

'X' can be:

'-': syntax error. Cannot parse the command at all.

'n': node error.

'm': method error.

property error.

YYY: error code, which can be one of the followings:

YYY: error code	Name	Default text
000	Lw3ErrorCodes_None	
001	Lw3ErrorCodes_Syntax	Syntax error
002	Lw3ErrorCodes_NotFound	Not found
003	Lw3ErrorCodes_AlreadyExists	Already exists
004	Lw3ErrorCodes_InvalidValue	Invalid value
005	Lw3ErrorCodes_IllegalParamCount	Illegal parameter count
006	Lw3ErrorCodes_IllegalOperation	Illegal operation
007	Lw3ErrorCodes_AccessDenied	Access denied
008	Lw3ErrorCodes_Timeout	Timeout
009	Lw3ErrorCodes_CommandTooLong	Command too long
010	Lw3ErrorCodes_InternalError	Internal error
011	Lw3ErrorCodes NotImplemented	Not implemented

## 7.1.4. Prefix Summary

The following prefixes are defined in the LW3 protocol:

'n-': a node,

'nE': an error for a node,

'nm': a manual for a node,

'pr': a read-only property,

'pw': read-write property,

'pE': an error for the property,

'pm': a manual for the property,

'm-': a method,

'm0': a response after a success method execution,


'mF': a response after a failed method execution,

'mE': an error for a method,

'mm': a manual for a method.

## 7.2. The Tree Structure of the Receiver

The /MEDIA node is used by the LDC to connect input ports to output ports on different layers. Each subnode of /MEDIA is representing a layer, e.g. video (/MEDIA/VIDEO), audio (/MEDIA/AUDIO) or RS-232 (/MEDIA/UART). Each layer has a crosspoint to define connections between the ports associated with the layer, all of them are represented by a specific node. E.g. the video layer node is /MEDIA/VIDEO: under the video layer node, the video crosspoint node (XP) and the video ports (I1, O1, ...) are located.



INFO: The tree structure is available in the Advanced view of LDC, see the Advanced View Window section.

## 7.3. LW3 Commands

#### 7.3.1. Get Command

The 'GET' command can be used to get the child nodes, properties and methods of a specific node. It can also be used to get the value of a property.

## The Response Format

The first two characters of a response unambiguously identify the type of the element that the response line concerns. The first character is the type of the element (node, property or method), the second is for miscellaneous information (e.g. read/write rights).

The defined prefixes are:

'n-': node

'pr': property - only readable

'pw': property - writable, readable

'm-': method executable

After the prefix, the response contains the full path of the node, property or method after a space character.

#### Get All Children of a Node

Get all of the child nodes of a parent node, with one GET command.

Command format: GET●[nodePath]

Response format: n-●[nodePath]

Example:

```
> GET /MEDIA
< n- /MEDIA/VIDEO
< n- /MEDIA/AUDIO
< n- /MEDIA/UART
< n- /MEDIA/IR
< n- /MEDIA/RELAY
< n- /MEDIA/ETHERNET
```

## Get All Properties and Methods of a Node

Get all properties and methods of a node, with one GET command and asterisk character.

Command format: GET●[nodePath].\*

**Response format**: (for properties)

pX•[nodePath].[propertyName]=[parameter]

#### Legend:

X can be:

'r': read-only 'w': read-write

Response format: (for methods)

m-•[nodePath]:[methodName]

#### Example:

```
> GET /EDID.*
< pr /EDID.EdidStatus=D1:E1
< m- /EDID:switch
< m- /EDID:switchAll
< m- /EDID:copy
< m- /EDID:delete
< m- /EDID:reset</pre>
```

## Get All Child Nodes, Properties and Methods of a Node

Get all child nodes, properties and methods of a node with one command, without using a wild card.

**Command format**: GETALL●[nodePath]

Response format: (for nodes)

n-•[nodePath]

Response format: (for properties)

pX•[nodePath].[propertyName]=[parameter]

Legend:

X can be:

'r': read-only 'w': read-write

**Response format**: (for methods)

m-•[nodePath]:[methodName]

#### Example:

```
> GETALL /EDID
< n- /EDID/F
< n- /EDID/D
< n- /EDID/U
< n- /EDID/E
< pr /EDID.EdidStatus=D1:E1
< m- /EDID:switch
< m- /EDID:switchAll
< m- /EDID:copy
< m- /EDID:delete
< m- /EDID:reset</pre>
```

#### 7.3.2. Set Command

The setter command can be used to modify the value of a property.

**Command format**: SET•[nodePath].[propertyName]=[newPropertyValue]

#### Response format:

The response for setting a property to a new value is the same as the response for the 'GET' command. The value in the response is the new value if the execution of the 'SET' command was successful, otherwise the unmodified 'old value' with an error message.

pw•[nodePath].[propertyName]=[newPropertyValue]

#### Example:

```
> SET /SYS/MB/RS232.Rs232Mode=1
< pw /SYS/MB/RS232.Rs232Mode=1
```

## **Error response format**:

If there were errors during setting a property, an error message follows the unmodified property value.

pE•[nodePath].[propertyName]=[umodifiedValue]•%EXXX:Error message

**Legend**: XXX: error number.

## Examples:

```
> SET /SYS/MB/RS232.Rs232Mode=11
< pE /SYS/MB/RS232.Rs232Mode %E004:Invalid value
```

```
> SET /SYS/MB/RS232/Local.ActiveProtocol=LW3
< pE %E004:Writing read-only property
```

#### 7.3.3. Invocation

A method can be invoked with the help of the 'CALL' command.

**Command format**: CALL•[nodePath]:[methodName]([parameter])

#### Response format:

The response for a method execution is a state and a value. The state is mandatory and always defined if the method could be executed. It can be either a success or a failure. The value is optional and it can contain additional information, such as the reason why the state is a failure or a specific value when the state is success that the client can process. It is also possible to get an error message when the method could not be executed – e.g. the parameter was illegal - and hence not even the state of the execution could be specified.

mX•[nodePath]:[methodName]=Y

#### Legend:

X can be:

'O': if the execution is successful.

'F': if the execution is failed, but the method could be

executed.

'E': if the method could not be executed: e.g. illegal

parameter count.

Y can be:

- The return value of the method if any.
- It is valid that a method does not have any return value. In this case, the equal sign ('=') can be omitted.

#### Example:

```
> CALL /EDID:switch(D1:E1)
< m0 /EDID:switch</pre>
```

#### **Error response format**:

If there were errors during the execution, an error message is received, which follows the method name.

 $mE \bullet [nodePath] : [methodName] \bullet \% EXXX : Error \ message$ 

#### Example:

```
> CALL /EDID:switch(D1:R1)
< mE %E001:Syntax error</pre>
```

#### 7.3.4. Manual

For every node, property and method in the tree there is a manual. The manual is a human readable text that describes the syntax and provides a hint for how to use the primitives.

#### Command format:

for nodes: MAN•[nodePath]

for property: MAN•[nodePath].[propertyName]
for method: MAN•[nodePath]:[methodName]

#### **Response format:**

The human readable manual is separated by a space ('') character from the primitives.

for nodes: nm•[nodePath]•Human readable manual

for property: pm•[nodePath].[propertyName]•Human readable manual for method: mm•[nodePath]:[methodName]•Human readable manual

**Example**: (for a property)

```
> MAN /SYS/MB/RS232/Local.ActiveProtocol
< pm /SYS/MB/RS232/Local.ActiveProtocol ["LW2" | "LW3"] Active Protocol</pre>
```

**Example**: (for a method)

```
> MAN /SYS/MB/RS232/Local:factoryDefaults
< mm /SYS/MB/RS232/Local:factoryDefaults [] Restore factory default settings</pre>
```

## 7.3.5. Signature

For some command, the response can contain multiple lines. Each line is terminated with a carriage return (Cr, '\r') and line feed (Lf, '\n') characters. In several cases the number of the lines in the response cannot be determined in advance, e.g. the client is intended waiting for the whole response and also wants to be sure, that the received lines belong together and to the same command. In these cases, a special feature the 'signature' can be used.

The signature is a four digit long hexadecimal value that can be optionally placed before every command. In that case, the response to that particular command will also be preceded by the signature, and the corresponding lines will be between brackets.

**Command format**: XXXX#[command]

**Legend**: xxxx: 4-digit long hexadecimal value.

Response format:

```
{XXXX
[command lines]
}
```

#### Example:

```
> 1103#GET /MEDIA/UART.*

< {1103
< pr /MEDIA/UART.PortCount=2
< pr /MEDIA/UART.PortUI=P1:01209;P2:12224
< pr /MEDIA/UART.P1=LOCAL
< pr /MEDIA/UART.P2=TPS
< }</pre>
```

INFO: The lines of the signature are also Cr and Lf terminated.

## 7.3.6. Subscription

A user can subscribe to any node. Subscribe to a node means that the user will get a notification if any of the properties of the node is changed. These notifications are asynchronous messages - such as the ones described above - and hence, they are useful to keep the client application up-to-date, without receiving any unwanted information. When the user does not want to be informed about the changes anymore, he can simply unsubscribe from the node.

**ATTENTION!** The subscriptions are handled separately for connections. Hence, if the connection is terminated all registered subscriptions are deleted. After closing a connection the subscribe command has to be sent in order to get the notifications of the changes on that connection.

#### Subscribe to a Node

Command format: OPEN●[nodePath]

Response format: o-●[nodePath]

Example:

```
> OPEN /MEDIA/VIDEO
< o- /MEDIA/VIDEO
```

## **Subscribe to Multiple Nodes**

In order to subscribe to multiple nodes, the asterisk wild card can be used.

Command format: OPEN●[nodePath]/\*

Response format: o-●[nodePath]/\*

Example:

```
> OPEN /MEDIA/VIDEO/*
< o- /MEDIA/VIDEO/*
```

#### **Get the Active Subscriptions for the Current Connection**

Command format: OPEN

**Response format**: o-•[nodePath]

Example:

```
> OPEN

< o- /MEDIA/VIDEO

< o- /EDID

< o- /LOG
```

#### Unsubscribe from a Node

Command format: CLOSE●[nodePath]

Response format: c-●[nodePath]

Example:

```
> CLOSE /MEDIA/VIDEO
< c- /MEDIA/VIDEO
```

#### **Unsubscribe from Multiple Nodes**

Command format: CLOSE●[nodePath]/\*

Response format: c-●[nodePath]/\*

Example:

```
> CLOSE /MEDIA/VIDEO/*
< c- /MEDIA/VIDEO/*
```

## 7.3.7. Notifications about the Changes of the Properties

When the value of a property is changed and the user is subscribed to the node, which the property belongs to, an asynchronous notification is generated. This is notification is called as the 'change message'. The format of such a message is very similar to the response for the 'GET' command.

Format: CHG•[nodePath].[propertyName]=[newPropertyValue]

## Example:

```
< CHG /EDID.EdidStatus=F48:E1;F49:E2;F48:E3;F48:E4;F48:E5</pre>
```

#### A Short Example of How to Use the Subscription

In the following, an example is presented, how the subscriptions are working and how to use them. In the example, there are two independent users controlling the device through two independent connections ('Connection #1' and 'Connection #2'). The events in the rows occur after each other.

```
Connection #1

> OPEN /MEDIA/VIDEO/XP

< o- /MEDIA/VIDEO/XP.DestinationConnectionList

< pr /MEDIA/VIDEO/XP.DestinationConnectionList=I1;I1

> GET /MEDIA/VIDEO/XP.DestinationConnectionList

< pr /MEDIA/VIDEO/XP.DestinationConnectionList

< pr /MEDIA/VIDEO/XP.DestinationConnectionList=I1;I1

> CALL /MEDIA/VIDEO/XP.switch(I1:01)

< m0 /MEDIA/VIDEO/XP:switch

Connection #1 < CHG /MEDIA/VIDEO/XP.DestinationConnectionList=I1;I1</pre>
```

**Explanation**: The first user (Connection #1) set a subscription to a node. Later the other user (Connection #2) made a change, and thanks for the subscription, the first user got a notification about the change.

## 7.4. Formal Definitions

Method parameters and property values are specified in a modified version of Backus Naur Form (BNF). The syntax is the following:

## 7.5. System Commands

## 7.5.1. Query the Product Name

The name of the product is a read-only parameter and cannot be modified.

**Command format:** GET•/.ProductName

**Response format:** pr•/.ProductName=<Product\_name>

Example:

```
> GET /.ProductName
```

< pr /.ProductName=HDMI-TPS-RX110AY</pre>

#### 7.5.2. Set the Device Label

**ATTENTION!** The device label can be changed to a custom text in the Status tab of the LDC software. This writable parameter is not the same as the ProductName parameter.

Command format: SET●/MANAGEMENT/UID/DeviceLabel=<Custom\_name>

Response format: pw●/MANAGEMENT/UID/DeviceLabel=<Custom\_name>

The Device Label can be 39 character length and ASCII characters are allowed. Longer names are truncated.

#### Example:

```
> SET /MANAGEMENT/UID.DeviceLabel=RX110_Conference1
< pw /MANAGEMENT/UID.DeviceLabel=RX110_Conference1</pre>
```

## 7.5.3. Query the Serial Number

**Command format:** GET●/.SerialNumber

**Response format:** pr•/.SerialNumber=<serial\_nr>

Example:

```
> GET /.SerialNumber
```

< pr /.SerialNumber=87654321</pre>

## 7.5.4. Query the Firmware Version

**Command format:** GET●/SYS/MB.FirmwareVersion

**Response format:** pr•/SYS/MB.FirmwareVersion=<firmware\_version>

```
> GET /SYS/MB.FirmwareVersion
```

< pr /SYS/MB.FirmwareVersion=1.2.0b6</pre>

## 7.5.5. Identify the Device

Calling the method results the blinking of the status LEDs for 10 seconds. The feature helps to identify the device itself in the rack shelf.

Command format: CALL●/MANAGEMENT/UI:identifyMe()

Response format: mO●/MANAGEMENT/UI:identifyMe=

Example:

```
> CALL /MANAGEMENT/UI:identifyMe()
< mO /MANAGEMENT/UI:identifyMe</pre>
```

## 7.5.6. Resetting the Device

The receiver can be restarted – the current connections (LAN, RS-232, USB) will be terminated.

CALL•/SYS:reset()

Response format: mO•/SYS:reset=

Example:

```
> CALL /SYS:reset()
< m0 /SYS:reset=</pre>
```

## 7.5.7. Restore the Factory Default Settings

Command format: CALL●/SYS:factoryDefaults()

Response format: mO●/SYS:factoryDefaults=

Example:

```
> CALL /SYS:factoryDefaults()
< m0 /SYS:factoryDefaults=</pre>
```

The device is restarted, current connections are terminated, and the default settings are restored. See the complete list in the Factory Default Settings section.

## 7.6. Video Port Settings

INFO: Video port numbering can be found in the Input/Output Port Numbering section.

## 7.6.1. Query the Status of Source Port

**Command format**: GET•/MEDIA/VIDEO/XP.SourcePortStatus

**Response format**: pr•/MEDIA/VIDEO/XP.SourcePortStatus=[<I<sub>1</sub>>]

The response contains 5 ASCII characters for each port. The first character indicates the mute/lock state, the next four characters represent a 2-byte HEX code showing the current state of the input ports.

## Example:

```
> GET /MEDIA/VIDEO/XP.SourcePortStatus
< pr /MEDIA/VIDEO/XP.SourcePortStatus=T00EF</pre>
```

## Legend:

	Letter (Charac	eter 1)		T 0 0 A F
	Mute state	Lock state		
Т	Unmuted	Unlocked	Letter Mute / Lock statu	
L	Unmuted	Locked	Byte 1 Reserved character, always ( Reserved character, always (	
М	Muted	Unlocked	Emboddod audio / HDCD statu	
U	Muted	Locked	Byte 2 Signal present / Connection statu	s <del></del>

	Byte 1				Byte 2			
	Chara	cter 2	Character 3		Character 4		Character 5	
	BIT 7-6	BIT 5-4	BIT 3-2	BIT 1-0	BIT 7-6	BIT 5-4	BIT 3-2	BIT 1-0
	Reserved	Reserved	Reserved	Reserved	Embedded audio status	HDCP status	Signal present status	Connection status
0 0						Unkr	nown	
0 1						Rese	erved	
10	Reserved	Reserved	Reserved	Reserved	No embedded audio	Not encrypted	No signal	Not connected
11					Embedded audio presents	Encrypted	Signal presents	Connected

## Example and Explanation (T00EF):

T	0		0		E		F	
Unlocked,	0 0	0 0	0 0	0 0	11	1 0	11	11
Unmuted	Reserved	Reserved	Reserved	Reserved	Embedded audio presents	Not encrypted	Signal presents	Connected

## **The Most Common Received Port Status Responses**

	Т	(	)	(	)	P	4	-	4
TOOAA	Unlocked.	0 0	0 0	0 0	0 0	10	10	10	10
	Unmuted	Reserved	Reserved	Reserved	Reserved	No embedded audio	Not encrypted	No signal	Not connected
	Т	(	)	(	)	A	4	E	3
T00AB	Unlocked.	0 0	0 0	0 0	0 0	10	1 0	10	11
	Unmuted	Reserved	Reserved	Reserved	Reserved	No embedded audio	Not encrypted	No signal	Connected
	Т	(	)	(	)	, and the second	1	i	=
T00AF	Unlocked,	0 0	0 0	0 0	0 0	10	10	11	11
	Unmuted	Reserved	Reserved	Reserved	Reserved	No embedded audio	Not encrypted	Signal presents	Connected
	Т	(	)	(	)	E		i	=
TOOEF		0 0	0 0	00	0 0	1 1	10	11	11
T00EF	T Unlocked, Unmuted		I		I			_	
T00EF	Unlocked,	0 0 Reserved	0 0	0 0 Reserved	0 0	1 1 Embedded	1 0 Not encrypted	1 1 Signal presents	11
	Unlocked, Unmuted	0 0 Reserved	0 0 Reserved	0 0 Reserved	0 0 Reserved	1 1 Embedded audio presents	1 0 Not encrypted	1 1 Signal presents	1 1 Connected
T00EF	Unlocked, Unmuted	0 0 Reserved	0 0 Reserved	0 0 Reserved	0 0 Reserved	1 1 Embedded audio presents	1 0  Not encrypted	1 1 Signal presents	1 1 Connected
	Unlocked, Unmuted  T Unlocked,	0 0 Reserved 0 0 Reserved	0 0 Reserved 0 0	0 0 Reserved	0 0 Reserved 0 0 Reserved	1 1 Embedded audio presents  E 1 0 No embedded	Not encrypted  1 1  Line Encrypted	1 1 Signal presents  1 1 Signal	1 1 Connected  1 1 Connected
	Unlocked, Unmuted  T  Unlocked, Unmuted	0 0 Reserved 0 0 Reserved	1 1 Embedded audio presents  E 1 0 No embedded audio	Not encrypted  1 1  Line Encrypted	1 1 Signal presents  1 1 Signal presents	1 1 Connected  1 1 Connected			

## 7.6.2. Query the Status of Destination Port

**Command format**: GET●/MEDIA/VIDEO/XP.DestinationPortStatus

**Response format**: pr•/MEDIA/VIDEO/XP.DestinationPortStatus=[<0,>]

The response contains 5 ASCII characters for each port. The first character indicates the mute/lock state, the next 2-byte long HEX code showing the current state of the output port.

#### Example:

> GET /MEDIA/VIDEO/XP.DestinationPortStatus

< pr /MEDIA/VIDEO/XP.DestinationPortStatus=M00BF</pre>

Legend: See at previous section.

#### Example:

М	(	0		)	В		F	
Unlocked,	0 0	0 0	0 0	0 0	1 0	11	11	11
Muted	Reserved	Reserved	Reserved	Reserved	No embedded audio	Encrypted	Signal presents	Connected

## 7.6.3. Mute Input Port

**Command format:** CALL●/MEDIA/VIDEO/XP:muteSource(<I<sub>n</sub>>)

**Response format:** mO•/MEDIA/VIDEO/XP:muteSource

Example:

> CALL /MEDIA/VIDEO/XP:muteSource(I1)

< mO /MEDIA/VIDEO/XP:muteSource

## 7.6.4. Unmute Input Port

Command format: CALL●/MEDIA/VIDEO/XP:unmuteSource(<I<sub>n</sub>>)

**Response format**: mO●/MEDIA/VIDEO/XP:unmuteSource

Example:

> CALL /MEDIA/VIDEO/XP:unmuteSource(I1)

< mO /MEDIA/VIDEO/XP:unmuteSource

## 7.6.5. Lock Input Port

**Command format**: CALL•/MEDIA/VIDEO/XP:lockSource(<I<sub>n</sub>>)

**Response format**: mO●/MEDIA/VIDEO/XP:lockSource

Example:

> CALL /MEDIA/VIDEO/XP:lockSource(I1)

< mO /MEDIA/VIDEO/XP:lockSource

## 7.6.6. Unlock Input Port

**Command format**: CALL•/MEDIA/VIDEO/XP:unlockSource(<I<sub>n</sub>>)

Response format: mO•/MEDIA/VIDEO/XP:unlockSource

Example:

> CALL /MEDIA/VIDEO/XP:unlockSource(I1)

< mO /MEDIA/VIDEO/XP:unlockSource</pre>

## 7.6.7. Mute Output

**Command format**: CALL•/MEDIA/VIDEO/XP:muteDestination(<0,>)

**Response format**: mO●/MEDIA/VIDEO/XP:muteDestination

Example:

> CALL /MEDIA/VIDEO/XP:muteDestination(01)

< mO /MEDIA/VIDEO/XP:muteDestination</pre>

## 7.6.8. Unmute Output

**Command format**: CALL•/MEDIA/VIDEO/XP:unmuteDestination(<0<sub>n</sub>>)

**Response format**: mO●/MEDIA/VIDEO/XP:unmuteDestination

Example:

> CALL /MEDIA/VIDEO/XP:unmuteDestination(01)

< mO /MEDIA/VIDEO/XP:unmuteDestination</pre>

## 7.6.9. Lock Output

**Command format**: CALL●/MEDIA/VIDEO/XP:lockDestination(<O<sub>n</sub>>)

**Response format**: mO●/MEDIA/VIDEO/XP:lockDestination

Example:

> CALL /MEDIA/VIDEO/XP:lockDestination(01)

< mO /MEDIA/VIDEO/XP:lockDestination

## 7.6.10. Unlock Output

**Command format**: CALL●/MEDIA/VIDEO/XP:unlockDestination(<0<sub>n</sub>>)

**Response format**: mO●/MEDIA/VIDEO/XP:unlockDestination

Example:

> CALL /MEDIA/VIDEO/XP:unlockDestination(01)

< mO /MEDIA/VIDEO/XP:unlockDestination

## 7.6.11. HDCP Setting (Input Port)

HDCP capability can be enabled/disabled on the input ports, thus, non-encrypted content can be seen on a non-HDCP compliant display. See more information in the HDCP Management section.

Command format: SET●/MEDIA/VIDEO/<I<sub>n</sub>>.HdcpEnable=true|false

Response format: pw●/MEDIA/VIDEO/<I >.HdcpEnable=true|false

Example:

> SET /MEDIA/VIDEO/I1.HdcpEnable=false

< pw /MEDIA/VIDEO/I1.HdcpEnable=false</pre>

## 7.6.12. HDCP Setting (Output Port)

HDCP capability can be set to Auto/Always on the output ports, thus, non-encrypted content can be transmitted to a non-HDCP compliant display. See more information in the HDCP Management section.

Command format: SET●/MEDIA/VIDEO/<O<sub>n</sub>>.HdcpModeSetting=0|1

Response format: pw●/MEDIA/VIDEO/<O<sub>n</sub>>.HdcpModeSetting=0|1

Parameters:

.HdcpModeSetting	0	1
HDCP mode	Auto	Always

#### Example:

> SET /MEDIA/VIDEO/01.HdcpModeSetting=0

< pw /MEDIA/VIDEO/01.HdcpModeSetting=0</pre>

#### 7.6.13. Test Pattern Generator

The output ports can send a special image towards the sink devices for testing purposes. The setting is available on output ports with the below-listed parameters.

#### **Test Pattern Generator Mode Setting:**

Command format: SET●/MEDIA/VIDEO/<O<sub>n</sub>>.TpgMode=0|1|2

Response format: pw●/MEDIA/VIDEO/<O<sub>n</sub>>.TpgMode=0|1|2

Parameters:

.TpgMode	0	1	2		
	Disabled	Enabled	No signal mode		
Test pattern generator	The test pattern is not	The test pattern is	The test pattern is		
mode	displayed on the output	displayed on the output	displayed if there is no		
			signal on the output port		

#### Example:

> SET /MEDIA/VIDEO/01.TpgMode=2

< pw /MEDIA/VIDEO/01.TpgMode=2</pre>

## **Clock Source - The Clock Frequency of the Test Pattern**

Command format: SET●/MEDIA/VIDEO/<O<sub>n</sub>>.TpgClockSource=480|576|EXT Response format: pw●/MEDIA/VIDEO/<O<sub>p</sub>>.TpgClockSource=480|576|EXT

Parameters:

.TpgClockSource	480	576	EXT
Clock frequency	480p	576p	External clock (from actual TMDS source)

#### Example:

> SET /MEDIA/VIDEO/01.TpgClockSource=576

< pw /MEDIA/VIDEO/01.TpgClockSource=576</pre>


#### **Test Pattern**

Command format: SET●/MEDIA/VIDEO/<O<sub>n</sub>>.TpgPattern=<pattern>
Response format: pw●/MEDIA/VIDEO/<O<sub>c</sub>>.TpgPattern=<pattern>

Parameters:

<pre><pattern> RED GREEN BLUE BLACK WHITE RAMP CHESS BAR</pattern></pre>	BLACK WHITE RAMP CHESS BAR CYCLE	BLACK	BLUE	GREEN	RED	<pattern></pattern>
--	----------------------------------	-------	------	-------	-----	---------------------

Cycle setting means all the patterns are changed sequentially approx. in every 2 seconds.



## Example:

> SET /MEDIA/VIDEO/01.TpgPattern=GREEN

< pw /MEDIA/VIDEO/01.TpgPattern=GREEN</pre>

## 7.6.14. HDMI Mode Settings (Output Port)

Command format: SET●/MEDIA/VIDEO/<O<sub>n</sub>>.HdmiModeSetting=0|1|2

Response format: pw●/MEDIA/VIDEO/<O<sub>n</sub>>.HdmiModeSetting=0|1|2

Parameters:

.HdmiModeSetting	0	1	2
HDMI mode	Auto	DVI	HDMI

## Example:

> SET /MEDIA/VIDEO/01.HdmiModeSetting=2

< pw / MEDIA/VIDEO/01.HdmiModeSetting=2</pre>

## 7.6.15. Query the Recent TPS Mode

**Command format:** GET●/REMOTE/S<sub>n</sub>.tpsMode

**Response format:** pr•/REMOTE/S<sub>a</sub>.tpsMode=A|H|L|1|2

#### Parameters:

.tpsMode	Α	Н	L	1	2
TPS mode	Auto	HDBaseT	Long reach	LPPF1	LPPF2

## Example:

```
> GET /REMOTE/S1.tpsMode
```

< pr /REMOTE/S1.tpsMode=H</pre>

See more information about TPS modes in the TPS Interface section.

## 7.6.16. TPS Mode Settings

Command format: SET●/REMOTE/S<sub>n</sub>.tpsModeSetting=A|H|L|1|2

Response format: pw●/REMOTE/S<sub>n</sub>.tpsModeSetting=A|H|L|1|2

Parameters: See at previous section.

## Example:

```
> SET /REMOTE/S1.tpsModeSetting=A
```

< pw /REMOTE/S1.tpsModeSetting=A</pre>

See more information about TPS modes in the TPS Interface section.

## 7.7. Audio Port Settings

INFO: Audio port numbering can be found in the Input/Output Port Numbering section.

## 7.7.1. Query the Status of Source Port

Command format: GET•/MEDIA/AUDIO/XP.SourcePortStatus

**Response format**: pr•/MEDIA/AUDIO/XP.SourcePortStatus=[<I,>]


The response contains 5 ASCII characters for each port. The first character indicates the mute/lock state, the next four characters represent a 2-byte HEX code showing the current state of the input ports.

#### Example:

```
> GET /MEDIA/AUDIO/XP.SourcePortStatus
< pr /MEDIA/AUDIO/XP.SourcePortStatus=T000F</pre>
```

#### Legend:

Letter (Character 1)								
	Mute state Lock state							
Т	Unmuted	Unlocked						
L	Unmuted	Locked						
М	Muted	Unlocked						
U	Muted	Locked						



		Byt	e 1		Byte 2				
	Character 2 Character 3		Chara	cter 4	Character 5				
	BIT 7-6	BIT 5-4	BIT 3-2	BIT 1-0	BIT 7-6	BIT 5-4	BIT 3-2	BIT 1-0	
	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Signal present status	Connection status	
0.0							Unknown		
0 1							Rese	erved	
10	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	No signal	Not connected	
11							Signal presents	Connected	

## Example and Explanation (for input 2, M000B):

М	0		0			)	В	
Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	10	11
Muted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	No signal	Connected

#### **The Most Common Received Port Status Responses**

	Т	(	)	(	)	(	)	l l	4
T000A	Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	1 0	1 0
	Unmuted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	No signal	Not connected
Т		(	)	(	)	(	)	E	3
Т000В	Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	10	11
	Unmuted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	No signal	Connected
	Т	(	)	(	)	(	)	F	=
T000F	Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	11	11
	Unmuted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Signal presents	Connected

**Only for Phoenix audio port:** Character 5 is C (11 00) which means signal is present but the cable connection status is unknown. The explanation is Phoenix connector has no pin which can indicate the connection status so this is always unknown.

	Т		(	)	(	)	(	)	(	С	
•	T000C	Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	11	0 0	
		Unmuted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Signal presents	Unknown	

## 7.7.2. Query the Status of Destination Port

**Command format**: GET●/MEDIA/AUDIO/XP.DestinationPortStatus

**Response format**:  $pr \bullet / MEDIA / AUDIO / XP.Destination PortStatus = [<0,>;<0,>]$ 

The response contains 5 ASCII characters for each port. The first character indicates the mute/lock state, the next 2-byte long HEX code showing the current state of the output port.

## Example:

> GET /MEDIA/AUDIO/XP.DestinationPortStatus

< pr /MEDIA/AUDIO/XP.DestinationPortStatus=T000F;M000F</pre>

**Legend:** See at previous section.

## Example and Explanation (for output 2, M000F):

М	(	)	0		(	)	F		
Unlocked,	0 0	0 0	0 0	0 0	0 0	0 0	11	11	
Muted	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Signal presents	Connected	

## 7.7.3. Mute Input Port

**Command format:** CALL•/MEDIA/AUDIO/XP:muteSource(<I<sub>n</sub>>)

**Response format:** mO•/MEDIA/AUDIO/XP:muteSource

Example:

> CALL /MEDIA/AUDIO/XP:muteSource(I1)

< mO /MEDIA/AUDIO/XP:muteSource</pre>

## 7.7.4. Unmute Input Port

**Command format**: CALL•/MEDIA/AUDIO/XP:unmuteSource(<I<sub>n</sub>>)

Response format: mO•/MEDIA/AUDIO/XP:unmuteSource

Example:

> CALL /MEDIA/AUDIO/XP:unmuteSource(I1)

< mO /MEDIA/AUDIO/XP:unmuteSource

## 7.7.5. Mute Output

**Command format**: CALL•/MEDIA/AUDIO/XP:muteDestination(<0,>)

**Response format**: mO●/MEDIA/AUDIO/XP:muteDestination

Example:

> CALL /MEDIA/AUDIO/XP:muteDestination(01)

< mO /MEDIA/AUDIO/XP:muteDestination

#### 7.7.6. Unmute Output

**Command format**:  $CALL \bullet / MEDIA / AUDIO / XP:unmuteDestination (<0_n >)$ 

**Response format**: mO●/MEDIA/AUDIO/XP:unmuteDestination

Example:

> CALL /MEDIA/AUDIO/XP:unmuteDestination(01)

< mO /MEDIA/AUDIO/XP:unmuteDestination

## 7.7.7. Analog Audio Output Level Settings

## Volume (dB)

Command format: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.VolumedB=<level>
Response format: pw●/MEDIA/AUDIO/<O<sub>n</sub>>.VolumedB=<level>

Parameters: <level> Sets the output volume (attenuation) between -95.625 dB and 0 dB in step of

-0.375 dB. The value is rounded up if necessary to match with the step value.

#### Example:

```
> SET /MEDIA/AUDIO/02.VolumedB=-15
< pw /MEDIA/AUDIO/02.VolumedB=-15.00
```

## Volume (Percent)

ommand format: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.VolumePercent=<percent> pw●/MEDIA/AUDIO/<O<sub>n</sub>>.VolumePercent=<percent>

**Parameters**: <level> Sets the output volume (attenuation) between 100% and 0%, in step of 1%. The

value is rounded up if necessary to match with the step value.

#### Example:

```
> SET /MEDIA/AUDIO/02.VolumePercent=50
< pw /MEDIA/AUDIO/02.VolumePercent=50</pre>
```

#### Balance

Command format: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.Balance=<level>
Response format: pw●/MEDIA/AUDIO/<O<sub>n</sub>>.Balance=<level>

Parameters: <evel> Sets the balance; -100 means left balance, 100 means right balance, step

is 1. Center is 0 (default).

#### Example:

```
> SET /MEDIA/AUDIO/02.Balance=0
< pw /MEDIA/AUDIO/02.Balance=0</pre>
```

## 7.7.8. Analog Audio Output Level Settings by Steps

#### Volume in dB

**Command format**: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.stepVolumedB=<step>

Parameters: <|evel> Sets the output volume (attenuation) between -95.625 dB and 0 dB in step of

pw•/MEDIA/AUDIO/<0\_>.VolumedB=<step>

-0.375 dB. The value is rounded up if necessary to match with the step value.

#### Example:

Response format:

> SET /MEDIA/AUDIO/02.stepVolumedB=5

< pw /MEDIA/AUDIO/02.stepVolumedB</pre>

#### **Volume in Percent**

ommand format: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.stepVolumePercent=<percent>

Response format: pw●/MEDIA/AUDIO/<O<sub>n</sub>>.stepVolumePercent=<percent>

**Parameters**: <level> Sets the output volume (attenuation) between 100% and 0%, in step of 1%. The

value is rounded up if necessary to match with the step value.

#### Example:

> SET /MEDIA/AUDIO/02.stepVolumePercent=15

< pw /MEDIA/AUDIO/02.stepVolumePercent</pre>

#### Balance

Command format: SET●/MEDIA/AUDIO/<O<sub>n</sub>>.stepBalance=<level>
Response format: pw●/MEDIA/AUDIO/<O<sub>n</sub>>.stepBalance=<level>

Parameters: <evel> Sets the balance; -100 means left balance, 100 means right balance, step

is 1. Center is 0 (default).

#### Example:

> SET /MEDIA/AUDIO/02.stepBalance=1

< pw /MEDIA/AUDIO/02.stepBalance</pre>

## 7.8. Network Configuration

## 7.8.1. Query the DHCP State

**Command format**: GET●/MANAGEMENT/NETWORK.DhcpEnabled

Response format: pw•/MANAGEMENT/NETWORK.DhcpEnabled=true|false

Example:

> GET /MANAGEMENT/NETWORK.DhcpEnabled

< pw /MANAGEMENT/NETWORK.DhcpEnabled=true</pre>

## 7.8.2. Change the DHCP State

**Command format**: SET●/MANAGEMENT/NETWORK.DhcpEnabled=true|false **Response format**: pw●/MANAGEMENT/NETWORK.DhcpEnabled=true|false

Example:

> SET /MANAGEMENT/NETWORK.DhcpEnabled=false

< pw /MANAGEMENT/NETWORK.DhcpEnabled=false</pre>

## 7.8.3. Query the IP Address

**Command format**: GET●/MANAGEMENT/NETWORK.lpAddress

Response format: pr•/MANAGEMENT/NETWORK.lpAddress=<IP\_Address>

Example:

> GET /MANAGEMENT/NETWORK.IpAddress

< pr /MANAGEMENT/NETWORK.IpAddress=192.168.0.100</pre>

## 7.8.4. Change the IP Address (Static)

Command format: SET●/MANAGEMENT/NETWORK.StaticIpAddress=<IP\_address>
Response format: pw●/MANAGEMENT/NETWORK.StaticIpAddress=<IP\_address>

Example:

> SET /MANAGEMENT/NETWORK.StaticIpAddress=192.168.0.85

< pw /MANAGEMENT/NETWORK.StaticIpAddress=192.168.0.85</pre>

## 7.8.5. Query the Subnet Mask

Command format: GET●/MANAGEMENT/NETWORK.NetworkMask

**Response format**: pr●/MANAGEMENT/NETWORK.NetworkMask=<netmask>

Example:

> GET /MANAGEMENT/NETWORK.NetworkMask

< pr /MANAGEMENT/NETWORK.NetworkMask=255.255.255.0</pre>

## 7.8.6. Change the Subnet Mask (Static)

Command format: SET●/MANAGEMENT/NETWORK.StaticNetworkMask=<netmask>

Response format: pw●/MANAGEMENT/NETWORK.StaticNetworkMask=<netmask>

Example:

> SET /MANAGEMENT/NETWORK.StaticNetworkMask=255.255.255.0

< pw /MANAGEMENT/NETWORK.StaticNetworkMask=255.255.25.0</pre>

## 7.8.7. Query the Gateway Address

**Command format**: GET•/MANAGEMENT/NETWORK.GatewayAddress

Response format: pr•/MANAGEMENT/NETWORK.GatewayAddress=<gw\_address>

Example:

> GET /MANAGEMENT/NETWORK.GatewayAddress

< pr /MANAGEMENT/NETWORK.GatewayAddress=192.168.0.1</pre>

## 7.8.8. Change the Gateway Address (Static)

Command format: SET●/MANAGEMENT/NETWORK.StaticGatewayAddress=<gw\_address>

Response format: pw●/MANAGEMENT/NETWORK.StaticGatewayAddress=<gw\_address>

Example:

> SET /MANAGEMENT/NETWORK.StaticGatewayAddress=192.168.0.5

< pw /MANAGEMENT/NETWORK.StaticGatewayAddress=192.168.0.5</pre>

## 7.9. RS-232 Port Configuration

INFO: Serial (local and link) port numbering can be found in the Input/Output Port Numbering section.

#### 7.9.1. Protocol Setting

Command format: SET●/MEDIA/UART/<P<sub>n</sub>>.ControlProtocol=0|1

Response format: pw●/MEDIA/UART/<P<sub>n</sub>>.ControlProtocol=0|1

Parameters:

.ControlProtocol	0	1
RS-232 protocol mode	LW2	LW3

#### Example:

> SET /MEDIA/UART/P1.ControlProtocol=1

< pw /MEDIA/UART/P1.ControlProtocol=1</pre>

## 7.9.2. BAUD Rate Setting

Command format: SET●/MEDIA/UART/<P<sub>n</sub>>.Baudrate=0|1|2|3|4|5|6|7

Response format: pw●/MEDIA/UART/<P<sub>n</sub>>.Baudrate=0|1|2|3|4|5|6|7

Parameters:

.Baudrate	0	1	2	3	4	5	6	7
BAUD rate value	4800	7200	9600	14400	19200	38400	57600	115200

#### Example:

> SET /MEDIA/UART/P1.Baudrate=2

< pw /MEDIA/UART/P1.Baudrate=2</pre>

## 7.9.3. Databit Setting

Command format: SET●/MEDIA/UART/<P<sub>n</sub>>.DataBits=8|9

Response format: pw●/MEDIA/UART/<P<sub>n</sub>>.DataBits=8|9

Example:

> SET /MEDIA/UART/P1.DataBits=8

< pw /MEDIA/UART/P1.DataBits=8</pre>

## 7.9.4. Stopbits Setting

Command format: SET●/MEDIA/UART/<P<sub>n</sub>>.StopBits=0|1|2

Response format: pw●/MEDIA/UART/<P<sub>n</sub>>.StopBits=0|1|2

Parameters:

.StopBits	0	1	2
Stopbit value	1	1,5	2

#### Example:

> SET /MEDIA/UART/P1.StopBits=0

< pw /MEDIA/UART/P1.StopBits=0</pre>

## 7.9.5. Parity Setting

**Command format**: SET●/MEDIA/UART/<P<sub>n</sub>>.Parity=0|1|2

**Response format**: pw●/MEDIA/UART/<P<sub>n</sub>>.Parity=0|1|2

Parameters:

.Parity	0	1	2	
Parity setting	no parity	odd	even	

#### Example:

> SET /MEDIA/UART/P1.Parity=0

< pw /MEDIA/UART/P1.Parity=0</pre>

## 7.9.6. RS-232 Operation Mode

Command format:  $SET \bullet / MEDIA / UART / < P_n > .Rs232 Mode = 0 | 1 | 2$ Response format:  $pw \bullet / MEDIA / UART / < P_n > .Rs232 Mode = 0 | 1 | 2$ 

Parameters:

.Rs232Mode	0	1	2
RS-232 operation mode	Pass-through	Control	Command injection

## Example:

> SET /MEDIA/UART/P1.Rs232Mode=1

< pw /MEDIA/UART/P1.Rs232Mode=1</pre>

#### **Command Injection Mode**

**Command format**: SET $\bullet$ /MEDIA/UART/<P<sub>n</sub>>.CommandInjectionEnable=true|false **Response format**: pw $\bullet$ /MEDIA/UART/<P<sub>n</sub>>.CommandInjectionEnable=true|false

Example:

> SET /MEDIA/UART/P1.CommandInjectionEnable=true
< pw /MEDIA/UART/P1.CommandInjectionEnable=true</pre>

**ATTENTION!** The local RS-232 and TPS serial link are mirrored. If you change the RS-232 mode on P1 (local) port, the P2 (TPS serial link) will also be changed.

**ATTENTION!** The Command injection status is stored in another read-only property: /MEDIA/UART/<P<sub>n</sub>>.CommandInjectionStatus.

## 7.10. Sending Message via the Communication Ports

## 7.10.1. Sending Message via TCP Port

The device can be used for sending a message to a certain IP:port address. The three different commands allow controlling the connected (third-party) devices.

## **Sending TCP Message**

The command is for sending a command messages in ASCII-format with an option for escaping special charaters.

CALL●/MEDIA/ETHERNET.tcpMessage(<IP\_address>:<port\_no>=<message>)

**Response format**: mO●/MEDIA/ETHERNET:tcpMessage

Example:

> CALL /MEDIA/ETHERNET.tcpMessage(192.168.0.20:5555=PWR0\x0d\x0a)

< mO /MEDIA/ETHERNET:tcpMessage

## **Escaping in the Message**

When commands need to be separated by <CR><LF> charaters to be recognized by the controlled device, then they need to be escaped. You can use the following format for escaping:

<command<sub>1</sub>><\x0d\x0a><command<sub>2</sub>><\x0d\x0a>...<command<sub>2</sub>><\x0d\x0a>

#### **Sending Text Message**

The command is for sending a text message in ASCII-format.

INFO: Escaping will not be processed using the tcpText command.

CALL • / MEDIA / ETHERNET.tcpText(<IP\_address>:<port\_no> = <message>)

**Response format**: mO●/MEDIA/ETHERNET:tcpText

Example:

```
> CALL /MEDIA/ETHERNET.tcpText(192.168.0.20:5555=pwr_on)
< mO /MEDIA/ETHERNET:tcpText
```

#### **Sending Binary Message**

The command is for sending a binary message in HEX format.

INFO: Escaping will not be processed using the tcpBinary command.

**Command format**: CALL•/MEDIA/ETHERNET.tcpBinary(<IP\_address>:<port\_no>=<message>)

**Response format**: mO●/MEDIA/ETHERNET:tcpBinary

Example:

```
> CALL /MEDIA/ETHERNET.tcpBinary(192.168.0.20:5555=010000000616200000cdcc2c40)
< mO /MEDIA/ETHERNET:tcpBinary
```

## 7.10.2. Sending Message via UDP Port

The device can be used for sending a message to a certain IP:port address. The three different commands allow controlling the connected (third-party) devices.

## **Sending UDP Message**

The command is for sending a command messages in ASCII-format with an option for escaping special charaters.

Command format: CALL • / MEDIA / ETHERNET. udpMessage (< IP\_address>:< port\_no> = < message>)

**Response format**: mO●/MEDIA/ETHERNET:udpMessage

Example:

```
> CALL /MEDIA/ETHERNET.udpMessage(192.168.0.20:5555=PWR0\x0d\x0a)
< mO /MEDIA/ETHERNET:udpMessage
```

## **Escaping in the Message**

When commands need to be separated by <CR><LF> charaters to be recognized by the controlled device, then they need to be escaped. You can use the following format for escaping:

```
<command<sub>1</sub>><\x0d\x0a><command<sub>2</sub>><\x0d\x0a>...<command<sub>n</sub>><\x0d\x0a>
```

#### **Sending Text Message**

The command is for sending a text message in ASCII-format.

INFO: Escaping will not be processed using the udpText command.

Command format: CALL

/MEDIA/ETHERNET.udpText(<IP\_address>:<port\_no>=<message>)

**Response format**: mO●/MEDIA/ETHERNET:udpText

Example:

```
> CALL /MEDIA/ETHERNET.udpText(192.168.0.20:5555=pwr_on)
< mO /MEDIA/ETHERNET:udpText
```

#### **Sending Binary Message**

The command is for sending a binary message in HEX format.

INFO: Escaping will not be processed using the udpBinary command.

**Command format**: CALL●/MEDIA/ETHERNET.udpBinary(<IP\_address>:<port\_no>=<message>)

**Response format**: mO●/MEDIA/ETHERNET:udpBinary

Example:

```
> CALL /MEDIA/ETHERNET.udpBinary(192.168.0.20:5555=01000000061620000cdcc2c40)
< mO /MEDIA/ETHERNET:udpBinary
```

## 7.10.3. Sending Message via an RS-232 Port

The RS-232 ports can be used for sending a command message to a device which can be controlled over serial port. Both local RS-232 and extended link RS-232 ports can be used. The three different commands allow to use different message formats.

## **Sending Message**

The command is for sending a command messages in ASCII-format with an option for escaping special charaters.

**Command format**: CALL•/MEDIA/UART/<P<sub>n</sub>>.sendMessage(<message>)

**Response format**: mO•/MEDIA/UART/<P<sub>a</sub>>:sendMessage

Example:

```
> CALL /MEDIA/UART/P1.sendMessage(PWR0\x0d\x0a)
< mO /MEDIA/UART/P1:sendMessage
```

## **Escaping in the Message**

When commands need to be separated by <CR><LF> charaters to be recognized by the controlled device, then they need to be escaped. You can use the following format for escaping:

```
<command<sub>1</sub>><\x0d\x0a><command<sub>2</sub>><\x0d\x0a>...<command<sub>n</sub>><\x0d\x0a>
```

#### **Sending Text Message**

The command is for sending a text message in ASCII-format.

INFO: Escaping will not be processed using the sendText command.

CALL • / MEDIA / UART / < P . > . sendText(< message > )

**Response format**: mO●/MEDIA/UART/<P<sub>n</sub>>:sendText

Example:

```
> CALL /MEDIA/UART/P2.sendText(pwr on)
```

< mO /MEDIA/UART/P2:sendText</pre>

#### **Sending Binary Message**

The command is for sending a binary message in HEX format.

INFO: Escaping will not be processed using the sendBinaryMessage command.

CALL•/MEDIA/UART/<P\_>.sendBinaryMessage(<message>)

**Response format**: mO●/MEDIA/UART/<P<sub>a</sub>>:sendBinaryMessage

Example:

```
> CALL /MEDIA/UART/P1.sendBinaryMessage(0100000061620000cdcc2c40)
```

< mO /MEDIA/UART/P1:sendBinaryMessage</pre>

## 7.11. Infrared Port Configuration

INFO: Infrared (local and link) port numbering can be found in the Input/Output Port Numbering section.

## 7.11.1. Enable Command Injection Mode

Command format: $SET \bullet / MEDIA / IR / < S|D_n > .CommandInjectionEnable = true|false$ Response format: $pw \bullet / MEDIA / IR / < S|D_n > .CommandInjectionEnable = true|false$ 

Example:

```
> SET /MEDIA/IR/S1.CommandInjectionEnable=true
```

< pw /MEDIA/IR/S1.CommandInjectionEnable=true</pre>

## 7.11.2. Change Command Injection Port Number

**Command format**:  $SET \bullet / MEDIA / IR / < S|D_n > . CommandInjectionPort = < port_no >$ **Response format**:  $pw \bullet / MEDIA / IR / < S|D_n > . CommandInjectionPort = < port_no >$ 

Example:

```
> SET /MEDIA/IR/S1.CommandInjectionPort=9001
< pw /MEDIA/IR/S1.CommandInjectionPort=9001</pre>
```

## 7.11.3. Enable/Disable Output Signal Modulation

**Command format**: SET $\bullet$ /MEDIA/IR/<D<sub>n</sub>>.EnableModulation=true|false **Response format**: pw $\bullet$ /MEDIA/IR/<D<sub>n</sub>>.EnableModulation=true|false

Example:

```
> SET /MEDIA/IR/D2.EnableModulation=false
< pw /MEDIA/IR/D2.EnableModulation=false</pre>
```

#### Explanation:

Signal modulation is turned off on TPS IR output line (D2).

INFO: The default setting value is "true" (enabled).

## 7.12. Relay Port Settings

## 7.12.1. Set Relay Connection State

Command format: SET●/MEDIA/RELAY/<P $_n$ >.Output=O|C Response format: pw●/MEDIA/RELAY/<P $_n$ >.Output=O|C

Parameters:

.Output	0	С
Relay connection state	Open	Closed

#### Example:

```
> SET /MEDIA/RELAY/P1.Output=C
< pw /MEDIA/RELAY/P1.Output=C</pre>
```

Explanation: P1 relay port is set to be closed.

# 7.13. EDID Management

## 7.13.1. Query the Emulated EDIDs

Command format: GET●/EDID.EdidStatus

**Response format**: pr•/EDID.EdidStatus=<E\_loc>:<E<sub>1</sub>>;<E\_loc>:<E<sub>2</sub>>;...;<E\_loc>:<E<sub>n</sub>>

Example:

```
> GET /EDID.EdidStatus
< pr /EDID.EdidStatus=D1:E1</pre>
```

## Explanation:

Emulated EDID memory for input port is listed with the EDID number that is currently emulated on the input.

## 7.13.2. Query the Validity of a Dynamic EDID

**Command format**: GET ● /EDID/D/D<sub>n</sub>. Validity

**Response format**: pr•/EDID/D/D<sub>a</sub>.Validity=true|false

Example:

```
> GET /EDID/D/D1.Validity
< pr /EDID/D/D1.Validity=true</pre>
```

## Explanation:

The 'Validity' property is true, valid EDID is stored in D1 memory place.

## 7.13.3. Query the Preferred Resolution of an User EDID

**Command format**: GET•/EDID/U/U<sub>a</sub>.PreferredResolution

**Response format**: pr•/EDID/U/U<sub>a</sub>.PreferredResolution=referred\_resolution>

Example:

```
> GET /EDID/U/U2.PreferredResolution
< pr /EDID/U/U2.PreferredResolution=1920x1080p60.00Hz</pre>
```

INFO: Use the "Manufacturer" property to query the manufacturer and the "MonitorName" property to query the name of the monitor.

## 7.13.4. Emulating an EDID to an Input Port

Command format: CALL•/EDID:switch(<source>:<destination>)

**Response format**: mO●/EDID:switch

Example:

```
> CALL /EDID:switch(F49:E2)
< m0 /EDID:switch</pre>
```

## Legend:

<source>: Source EDID memory place: Factory / User / Dynamic.
<destination>: The emulated EDID memory of the desired input port.

## 7.13.5. Copy an EDID to User Memory

Command format: CALL●/EDID:copy(<D<sub>p</sub>>|<E<sub>p</sub>>|<F<sub>p</sub>>|<U<sub>p</sub>>:<U<sub>m</sub>>)

**Response format**: mO●/EDID:copy

Example:

```
> CALL /EDID:copy(D1:U1)
< mO /EDID:copy
```

#### Explanation:

The EDID of the last connected sink of D1 (Output 1) has been copied to U1.

## 7.13.6. Deleting an EDID from User Memory

Command format: CALL • / EDID: delete(<U\_>>)

**Response format**: mO●/EDID:delete

Example:

```
> CALL /EDID:delete(U1)
< m0 /EDID:delete</pre>
```

## 7.13.7. Resetting the Emulated EDIDs

Command format: CALL●/EDID:reset()

Response format: mO●/EDID:reset

Example:

```
> CALL /EDID:reset()
< m0 /EDID:reset</pre>
```

**Explanation**: Calling this method switches all emulated EDIDs to factory default one. See the table in the Factory EDID List section.

# 7.14. LW3 Commands - Quick Summary

## **System Commands**

	Operation / Path		
7.5.1	Query the Product Name		
	/.ProductName		
7.5.2	Set the Device Label		
7.5.2	/MANAGEMENT/UID.DeviceLabel		
7.5.3	Query the Serial Number		
7.5.3	/.SerialNumber		
7.5.4	Query the Firmware Version		
7.5.4	/SYS/MB.FirmwareVersion		
7.5.5	Identify the Device		
7.5.5	/MANAGEMENT/UI:identifyMe		
7.5.6	Resetting the Device		
7.5.6	/SYS:reset()		
7.5.7	Restore the Factory Default Settings		
7.3.7	/SYS:factoryDefaults()		

## **Video Port Settings**

	Operation / Path		
7.6.1	Query the Status of Source Port		
7.0.1	/MEDIA/VIDEO/XP.SourcePortStatus		
7.6.2	Query the Status of Destination Port		
7.0.2	/MEDIA/VIDEO/XP.DestinationPortStatus		
7.6.3	Mute Input Port		
7.0.3	/MEDIA/VIDEO/XP:muteSource( <input/> )		
7.6.4	Unmute Input Port		
7.0.4	/MEDIA/VIDEO/XP:unmuteSource( <input/> )		
7.6.5	Lock Input Port		
7.0.5	/MEDIA/VIDEO/XP:lockSource( <input/> )		
7.6.6	Unlock Input Port		
7.0.0	/MEDIA/VIDEO/XP:unlockSource( <input/> )		

	Operation / Path		
7.6.7	Mute Output		
7.0.7	/MEDIA/VIDEO/XP:muteDestination( <output>)</output>		
7.6.8	Unmute Output		
7.0.8	/MEDIA/VIDEO/XP:unmuteDestination( <output>)</output>		
7.6.9	Lock Output		
7.0.9	/MEDIA/VIDEO/XP:lockDestination( <output>)</output>		
7.6.10	Unlock Output		
7.0.10	/MEDIA/VIDEO/XP:unlockDestination( <output>)</output>		
7.6.11	HDCP Setting (Input Port)		
7.0.11	/MEDIA/VIDEO/ <input/> .HdcpEnable		
7.6.12	HDCP Setting (Output Port)		
7.0.12	/MEDIA/VIDEO/ <output>.HdcpModeSetting</output>		
7.6.13	Test Pattern Generator		
7.0.13	/MEDIA/VIDEO/ <output>.TpgMode TpgClockSource TpgPattern</output>		
7.6.14	HDMI Mode Settings (Output Port)		
7.0.14	/MEDIA/VIDEO/ <output>.HdmiModeSetting</output>		
7.6.15	Query the Recent TPS Mode		
7.0.13	/REMOTE/S1.tpsMode		
7.6.16	TPS Mode Settings		
7.0.10	/REMOTE/S1.tpsModeSetting		

## **Audio Port Settings**

Operation / Path		
7.7.1	Query the Status of Source Port	
	/MEDIA/AUDIO/XP.SourcePortStatus	
7.7.2	Query the Status of Destination Port	
1.1.2	/MEDIA/AUDIO/XP.DestinationPortStatus	
7.7.3	Mute Input Port	
7.7.3	/MEDIA/AUDIO/XP:muteSource( <input/> )	
7.7.4	Unmute Input Port	
	/MEDIA/AUDIO/XP:unmuteSource( <input/> )	

	Operation / Path		
7.7.5	Mute Output		
	/MEDIA/AUDIO/XP:muteDestination( <output>)</output>		
7.7.6	Unmute Output		
	/MEDIA/AUDIO/XP:unmuteDestination( <output>)</output>		
7.7.7	Analog Audio Output Level Settings		
	/MEDIA/AUDIO/ <output>.VolumedB VolumePercent Balance</output>		
7.7.8	Analog Audio Output Level Settings by Steps		
	/MEDIA/AUDIO/ <output>.stepVolumedB stepVolumePercent stepBalance</output>		

## **Network Configuration**

	Operation / Path		
7.8.1	Query the DHCP State		
7.0.1	/MANAGEMENT/NETWORK.DhcpEnabled		
7.8.2	Change the DHCP State		
7.0.2	/MANAGEMENT/NETWORK.DhcpEnabled		
7.8.3	Query the IP Address		
7.0.3	/MANAGEMENT/NETWORK.lpAddress		
7.8.4	Change the IP Address (Static)		
7.0.4	/MANAGEMENT/NETWORK.StaticlpAddress		
7.8.5	Query the Subnet Mask		
7.8.3	MANAGEMENT/NETWORK.NetworkMask		
7.8.6	Change the Subnet Mask (Static)		
7.8.0	/MANAGEMENT/NETWORK.StaticNetworkMask		
707	Query the Gateway Address		
7.8.7	/MANAGEMENT/NETWORK.GatewayAddress		
7.8.8	Change the Gateway Address (Static)		
7.8.8	/MANAGEMENT/NETWORK.StaticGatewayAddress		

## **RS-232 Port Configuration**

	Operation / Path
7.8.1	Query the DHCP State
	/MEDIA/UART/ <port_no>.ControlProtocol</port_no>
700	BAUD Rate Setting
7.9.2	/MEDIA/UART/ <port_no>.Baudrate</port_no>
7.9.3	Databit Setting
7.9.3	/MEDIA/UART/ <port_no>.DataBits</port_no>
7.9.4	Stopbits Setting
7.9.4	/MEDIA/UART/ <port_no>.StopBits</port_no>
7.9.5	Parity Setting
7.9.5	/MEDIA/UART/ <port_no>.Parity</port_no>
7.9.6	RS-232 Operation Mode
	/MEDIA/UART/ <port_no>.Rs232Mode</port_no>

## **Sending Message via the Communication Ports**

Operation / Path			
7.10.1	Sending Message via TCP Port		
7.10.1	/MEDIA/ETHERNET.tcpText tcpMessage tcpBinary		
7.10.2	Sending Message via UDP Port		
	/MEDIA/ETHERNET.udpText udpMessage udpBinary		
7.10.3	Sending Message via an RS-232 Port		
	/MEDIA/UART/ <port_no>.sendText sendMessage sendBinaryMessage</port_no>		

## **Infrared Port Configuration**

Operation / Path			
7.11.1	Enable Command Injection Mode		
7.11.1	/MEDIA/IR/ <port_no>.CommandInjectionEnable</port_no>		
7.11.2	Change Command Injection Port Number		
	/MEDIA/IR/ <port_no>.CommandInjectionPort</port_no>		
7.11.3	Enable/Disable Output Signal Modulation		
	/MEDIA/IR/ <port_no>.EnableModulation</port_no>		

## **Relay Port Settings**

Operation / Path		
7.12.1	Set Relay Connection State	
7.12.1	/MEDIA/RELAY/ <port_no>.Output</port_no>	

## **EDID Management**

	Operation / Path			
7101	Query the Emulated EDIDs			
7.13.1	/EDID.EdidStatus			
7100	Query the Validity of a Dynamic EDID			
7.13.2	/EDID/D/ <dynamic_edid_memory>.Validity</dynamic_edid_memory>			
7.13.3	Query the Preferred Resolution of an User EDID			
7.13.3	/EDID/U/ <user_edid_memory>.PreferredResolution</user_edid_memory>			
7.13.4	Emulating an EDID to an Input Port			
7.13.4	/EDID:switch( <source/> : <destination>)</destination>			
7.13.5	Copy an EDID to User Memory			
7.13.5	/EDID:copy( <source/> : <destination>)</destination>			
7.13.6	Deleting an EDID from User Memory			
7.13.0	/EDID:delete( <user_edid_memory>)</user_edid_memory>			
7.13.7	Resetting the Emulated EDIDs			
7.13.7	/EDID:reset()			



# **Firmware Upgrade**

The receiver can be upgraded by using Lightware Device Updater (LDU) software via Ethernet. The firmware pack with the necessary components (\*.lfp file) for your specific product, the LDU application, and the User's manual can be downloaded from the Support page of our website www.lightware.com.

- ▶ ABOUT THE FIRMWARE PACKAGE (LFP FILE)
- SHORT INSTRUCTIONS
- ▶ INSTALL AND UPGRADE
- DETAILED INSTRUCTIONS
- ▶ KEEPING THE CONFIGURATION SETTINGS
- ▶ REMOTE FIRMWARE UPGRADE OF CONNECTED LIGHTWARE DEVICES

**ATTENTION!** While the firmware is being upgraded, the normal operation mode is suspended as the receiver is switched to bootload mode. Signal processing is not performed. Do not interrupt the firmware upgrade. If any problem occurs, reboot the receiver and restart the process.

**ATTENTION!** The firmware upgrade process has an effect on the configuration and the settings of the device. For more details, please see the Keeping the Configuration Settings section before the upgrade.

## 8.1. About the Firmware Package (LFP File)

The firmware files are packed in an LFP package. You need only this file to do the upgrade on your device.

- The package contains all the necessary components, binary, and other files: You do not have to get further files.
- There is a descriptor file in the package that contains each firmware with version number and a list showing the compatible devices. The descriptor is displayed after loaded the LFP file in the LDU.

## 8.2. Short Instructions

- **Step 1.** Get the firmware pack and the Lightware Device Updater (LDU) application.
- Step 2. Install the LDU application.
- **Step 3.** Establish the connection between the computer and the device(s).
- Step 4. Start the LDU and follow the instructions shown on the screen.

## 8.3. Install and Upgrade

#### Installation for Windows OS

INFO: The application can be installed under Windows XP or above.

Run the installer. If the User Account Control drops a pop-up message click **Yes**. During the installation you will be prompted to select the type of the installation:

Normal install	Snapshot install	
Available for Windows and Mac OS X	Available for Windows	
The installer can update only this instance	Cannot be updated	
Only one updateable instance can exist	More than one different version	
for all users	can be installed for all users	

Comparison of install types

**ATTENTION!** Using the Normal install as the default value is highly recommended.


#### Installation for Mac OS X

INFO After the installation the Windows and the Mac application has the same look and functionality. This type of the installer is equal with the Normal install in case of Windows and results an updateable version with the same attributes.

Mount the DMG file with double clicking on it and drag the LDU icon over the Applications icon to copy the program into the Applications folder. If you want to copy the LDU into another location just drag the icon over the desired folder.

#### LDU Upgrade

Step 1. Run the application. In the welcome screen click on the button in the top right corner; the About window will appear. Click on the Check now button. The program checks the available updates on Lightware website and shows its version.



**Step 2.** Set the desired update settings in the **Options** section.

- If you do not want to check for the updates automatically, uncheck the **circle**, which contains the green tick.
- If you want to postpone the update, a reminder can be set with different delays from the drop down list.
- If the proxy settings traverse the update process, set the proper values then click the **OK** button.

**Step 3.** Press the **Update** button to download the new version; the installer will start.

# Proxy settings No proxy: System default Use HTTP proxy: Use SOCKS 5 proxy: Proxy host Proxy port: 8080 Proxy username: Proxy password: OK Cancel


## 8.4. Detailed Instructions

#### 8.4.1. Establish the Connection

Make sure that the computer and the device are connected via an Ethernet cable and the connection is established between them.

#### 8.4.2. Start the LDU and Follow the Instructions

After launching LDU the welcome screen will appear:




Pressing the 🏮 button a list will appear showing the supported devices:

Click on the **Extender** button on the main screen.

#### Step 1. Select the package.

Click on the Browse button and select the ".lfp" file that will be used for the upgrade.




Package information is displayed:

- General version info, creation date, short description,
- Devices which are compatible with the firmware,
- Components in the package with release notes.

Click on the Next button and follow the instructions.

TIPS AND TRICKS: Files with ".lfp" extension are associated to LDU during installation. If you double click on the ".lfp" file, the application is launched, the package is loaded automatically and above screen is shown.

#### Step 2. Select device.




The following step is to select the desired device(s). The available and supported devices are searched and listed automatically. If the desired device is not listed, update the list by clicking the **Refresh** button. Select the desired devices: highlight them with a **yellow cursor**, then click **OK**.

A tick mark can be seen in the Added column if the device was added by the user previously.

#### **Firmware Components**

The firmware components of the selected devices are listed on the following screen: installed and update versions. (Update version will be uploaded to the device.)



Add a device by clicking on the **Add device** button. The previous screen will be shown; select the desired device(s) and click on **OK**.

Remove a device by selecting it (highlight with yellow) and click on **Remove device** button, or click on **Remove all** button to empty the list.


Enabling **Factory reset** will perform factory default values for all settings in the device. Three different status can exist:

- Enabled by user: all settings will set to factory default values.
- Disabled by user: your settings will be saved and restored after upgrading.
- Enabled by default and not changeable by user: firmware upgrade must perform a factory reset to apply all changes coming with the new firmware version.

Click on the Next button to continue.

#### Step 3. Upgrade the device.

Click on the Start button to continue.



Two warning windows will pop up before starting upgrading the device:

 Do not unplug the power cable (or CATx cable from the TPS input port in case of PoE) and the LAN cable while the upgrade is in progress. Click OK to continue.




Please note the device presets will lost after the firmware upgrade.
 If you want to continue the procedure, click Yes.




You can save the device presets to offline file as well. See more details about the presets in the Configuration Cloning (Backup Tab) section.

When you confirmed the warnings, the upgrade process starts automatically.




**Details** button opens a new window where the process is logged – see below.



#### Step 4. Finish.

If the upgrade of a device is finished, the log can be opened by the **View** button on the right When all the tasks are finished, a window appears. Click **OK** to close and **Next** to display the summary page.



Repeat button starts the process again with the selected device(s).

Open logs button opens the temporary folder where the logs can be found.

**Export logs** by saving the files as a zipped file.

Press **Exit** to close the program.

If the upgrade failed, the progress bar of the device is changed to red; restart the device(s) and repeat the process.

## 8.5. Keeping the Configuration Settings

User can keep all configuration settings and restore to the device after firmware upgrading or can choose to perform a factory reset – it means all settings will be erased in the device. In case of factory reset you can save the settings of the device and restore it later. For the detailed information about saved data refer to the Content of Backup File section.


The following flow chart demonstrates how this function works in the background.



Flow chart of firmware upgrade

The details about the procedure: when firmware upgrade starts, the first step is making a backup of the settings of the device. The firmware package checks the backup data and if it is needed, a conversion is applied to avoid incompatibility problems between the firmware versions. If you do not want to keep configuration settings, you can set the **Factory reset** option enabled.

The instruction in the firmware package of the device will inform you about this function availability, reading it is highly recommended in every case.



Instructions page in the firmware package

**ATTENTION!** In specific cases restoring cannot be applied fully and certain settings are not copied back to the device. If a warning message appears, user can get back the original data from the backup. Logs of the upgrade procedure contain all backup data, it can be exported at the end of the upgrade procedure. Details about the procedure of log exporting can be found in the Detailed Instructions section. In case of any question, please contact <a href="mailto:support@lightware.com">support@lightware.com</a>.

**ATTENTION!** In certain cases, the new firmware version requires setting all parameters to set factory defaults. In this case, the "Factory reset" option is enabled by default and not changeable by the user, see details in the Detailed Instructions section.

ATTENTION! The feature is only supported by LDU version 1.3.0 and above.

## 8.6. Remote Firmware Upgrade of Connected Lightware Devices

Firmware of Lightware devices can be upgraded via another connected Lightware device without removing the device from the system. It means user does not have to connect directly to the upgradable device, it can be reached and flashed through other devices. It's a more comfortable way to keep up-to-date your Lightware devices.



There are two types of remote upgrading:


#### **Extended Upgrade**

- Intelligent devices can be upgraded via another intelligent or basic device via TPS or OPTS/OPTM link.
- For example, HDMI-TPS-RX110AY extenders can be upgraded via MMX6x2-HT series matrix or a HDMI-TPS-TX95 extender.

#### **Hosted Upgrade**

- Basic devices can be upgraded only via an intelligent device via TPS link.
- For example, TPS 95 series extenders can be upgraded via MMX6x2-HT series matrix or HDMI-TPS-RX110AY extenders.
- In case of hosted upgrade, the procedure is almost the same as described in Firmware upgrade –
   Detailed Instructions. The only difference is that the host device's name, and IP address appears
   beside the name of the device to be upgraded.

**ATTENTION!** During hosted upgrade the host device turned to bootload mode when the extender is upgraded. During the upgrade normal operation mode is suspended. When the upgrade is successfully finished, the normal operation mode is restored.



Remote device in device selection window

9. Troubleshooting HDMI-TPS-RX110AY – User's Manual 71



# **Troubleshooting**

Usually, if the system seems not to transport the signal as expected, the best strategy for troubleshooting is to check signal integrity through the whole signal chain starting from source side and moving forward to receiver end.

- Link to connections/cabling section.
- $\Box$  Link to front panel operation section.
- Link to LDC software section.
- Link to LW2 protocol commands section.
- Link to LW3 protocol commands section.

## 9.1. Use Case Studies

At first, check front panel LEDs and take the necessary steps according to their states. For more information about status, LEDs refer to the Front View and Rear View sections.

Symptom	Root cause	Action	Refer to
	V	Video signal	
No picture on the video output	Device or devices are not powered properly	Check the receiver and the other devices if they are properly powered; try to unplug and reconnect them.	₹ 3.3.1
	Cable connection problem	Cables must fit very well, check all the connectors (video and TPS cables).	₹0 3.3
	No incoming signal	If the TPS LINK LED does not light, no signal is present on the TPS input port. Check the source device and the CATx cable.	₩ 3.3
	TPS mode problem	Check the actual TPS mode and the selected modes of the extenders.	5.3.1
	The output is muted	Check the mute state of output port.	5.3.1
			LW2 6.3.5
			LW3 7.6.2
	Display is not able to receive the video format	Check the emulated EDID; select another (e.g. emulate the EDID of the display on	5.5
	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		LW3 7.13
HDCP is disabled Enable HDCP on the port.		Enable HDCP on the input and output	5.3.1
		port.	LW3 7.6.11
			LW3 7.6.12
Not the desired picture displayed	Video output is set to test pattern (no sync	Check Test Pattern settings in the HDMI output properties.	5.3.1
on the video screen) statically output			LW3 7.6.13
	Video output is set to test pattern (no sync screen) as there is no picture on video source	Check video settings of the source.	

9. Troubleshooting HDMI-TPS-RX110AY – User's Manual


Symptom	Root cause Action		Refer to
	A	udio signal	
No audio is present on output	· · · · · · · · · · · · · · · · · · ·		
	Output port is muted	Check the output port properties.	5.3.2
		LW LW	
			LW3 7.7.2
	Analog audio volume is set low	Check the Analog audio output port settings (volume).	5.3.2 LW3 7.7.7
HDMI output signal	HDMI mode was set to	Check the properties of the output port	5.3.1
contains no audio	DVI	and set to HDMI or Auto.	LW3 7.6.14
	DVI EDID is emulated	Check the EDID and select and HDMI	5.5
		EDID to emulate.	LW3 7.13
	RS	S-232 signal	
Connected serial device does not respond	Cable connection problem	Check the connectors to fit well; check the wiring of the plugs.	
	RS-232 settings are Check the port settings of t		5.6.1
	different	and/or the receiver and the connected serial device(s). Pay attention to Link	LW2 6.5
	and/or Local ports.		LW3 7.9
I • • • • • • • • • • • • • • • • • • •		Check the RS-232 mode settings	5.6.1
		(pass-through, control or command injection)	LW2 6.5.1
			LW3 7.9.6
		Network	
No LAN connection	Incorrect IP address is	Use dynamic IP address by enabling	4.1.2
can be established	set (fix IP)	DHCP option.	5.8.2
			LW2 6.4.2
			LW3 7.8.2
Restore the factory of fix IP).		Restore the factory default settings (with	4.1.3
		iix ie).	5.8.4
			LW2 6.2.11
			LW3 7.5.7
	IP address conflict Check the IP address of the other devices, too.		


Symptom Root cause		Action	Refer to	
	М	iscellaneous		
Function button is out of operation	Function button is locked	Unlock the button	5.8.1	
Error messages received always	Different protocol is set	Check the port protocol settings (LW2 / LW3) and use the proper protocol commands.	5.6.1 LW2 6.5.4 LW2 6.5.5 LW3 7.9.1	

9. Troubleshooting HDMI-TPS-RX110AY – User's Manual 73

## 9.2. How to Speed Up the Troubleshooting Process

Lightware's technical support team is always working hard to provide the fastest support possible. Our team's response time is one of the best in the industry and in the toughest of cases we can directly consult with the hardware or software engineer who designed the product to get the information from the most reliable source.





There are certain pieces of information that push us in the right direction to finding the root cause of the problem. If we receive most of this information in the first e-mail or it is gathered at the time when you call us, then there is a pretty high chance that we will be able to respond with the final solution right away.

#### This information is the following:

- Schematic (a pdf version is preferred, but a hand drawing is sufficient).
- Serial number(s) of the device(s) (it is either printed somewhere on the box or you can query it in the Device Controller software or on the built-in website).
- Firmware versions of the devices (please note that there may be multiple CPUs or controllers in the device and we need to know all of their firmware versions, a screenshot is the best option).
- Cable lengths and types (in our experience, it's usually the cable).
- Patch panels, gender changers or anything else in the signal path that can affect the transmission.
- Signal type (resolution, refresh rate, color space, deep color).
- Emulated EDID(s) (please save them as file and send them to us).
- Actions to take in order to re-create the problem (if we cannot reproduce the problem, it is hard for us to find the cause).
- Photo or video about the problem ('image noise' can mean many different things, it's better if we see it too).
- Error logs from the Device Controller software.
- In the case of Event Manager issue the event file and/or backup file from the Device Controller software.

The more of the above information you can give us the better. Please send these information to the Lightware Support Team (support@lightware.com) to speed up the troubleshooting process.

10. Technologies HDMI-TPS-RX110AY – User's Manual 74



# **Technologies**

The following sections contain descriptions and useful technical information how the devices work in the background. The content is based on experiences and cases we met in the practice. These sections help to understand features and technical standards like the followings:

- **▶** EDID MANAGEMENT
- ▶ HDCP MANAGEMENT
- **▶** PIXEL ACCURATE RECLOCKING

## 10.1. EDID Management


## 10.1.1. Understanding the EDID

The Extended Display Identification Data (EDID) is the passport of display devices (monitors, TV sets, projectors). It contains information about the capabilities of the display, such as supported resolutions, refresh rates (these are called Detailed Timings), the type and manufacturer of the display device, etc.

After connecting a source to a display (DVI, HDMI, DP), the source reads out the EDID to determine the resolution and refresh rate of the image to be transmitted.







**EDID Communication** 

Most DVI computer displays have 128-byte long EDID structure. However, Digital Televisions and HDMI capable displays may have another 128 bytes, which is called E-EDID and defined by CEA (Consumer Electronics Association). This extension contains information about additional Detailed Timings, audio capabilities, speaker allocation and HDMI capabilities. It is important to know that all HDMI capable devices must have CEA extension, but not all devices with CEA extension are HDMI capable.

#### **Common Problems Related to EDID**

Problem: "My system consists of the following: a computer, a

Lightware device, a WUXGA (1920x1200) LCD monitor, and an SXGA (1280x1024) projector. I would like to see the same image on the monitor and the projector. What EDID should I choose on the Lightware device?"

Solution: If you want to see the image on both displays, you need

to select the resolution of the smaller display (in this case SXGA), otherwise the smaller display may not show

the higher resolution image.

Problem: "I have changed to a different EDID on an input port of

the Lightware device to have a different resolution but

nothing happens."

Solution: Some graphics cards and video sources read out the

EDID only after power-up and later they do not sense that EDID has been changed. You need to restart your source

to make it read out the EDID again.

## 10.1.2. Advanced EDID Management

Each DVI sink (e.g. monitors, projectors, plasma displays, etc...) must support the EDID data structure. Source BIOS and operating systems are likely to query the sink using DDC2B protocol to determine what pixel formats and interface are supported. DVI standard uses EDID data structure to identify the monitor type and capabilities. Most DVI sources (VGA cards, set top boxes, etc.) will output DVI signal after accepting the connected sink's EDID information. In the case of EDID readout failure or missing EDID, the source will not output DVI video signal.

Lightware devices provide the Advanced EDID Management function that helps system integration. The built-in EDID Router can store and emulate factory pre-programmed- and User programmable EDIDs. The EDID of the attached monitors or projectors for each output are stored in a non-volatile memory. This way the EDID of a monitor is available when the monitor is unplugged or switched off.

Any EDID can be emulated on any input. An emulated EDID can be copied from the EDID router's memory (static EDID emulation), or from the last attached monitor's memory (dynamic EDID emulation). For example, the Lightware device can be set up to emulate a sink device, which is connected to one of the outputs. In this case, the EDID automatically changes, if the monitor is replaced with another display device (as long as it has a valid EDID).

EDID is independently programmable for all inputs without affecting each other. All inputs have their own EDID circuit.

INFO: The user is not required to disconnect the video cable to change an EDID as opposed to other manufacturer's products. EDID can be changed even if a source is connected to the input and powered ON.

INFO: When EDID has been changed, the router toggles the HOTPLUG signal for 2 seconds. Some sources do not sense this signal. In such cases, the source device must be restarted or powered OFF and ON again.

10. Technologies HDMI-TPS-RX110AY – User's Manual 75

## 10.2. HDCP Management

Lightware Visual Engineering is a legal HDCP adopter. Several functions have been developed which helps to solve HDCP related problems. Complex AV systems often have both HDCP and non-HDCP components. The receiver allows transmitting HDCP encrypted and unencrypted signals. The devices will be still HDCP compliant as they will never output an encrypted signal to a non-HDCP compliant display device. If an encrypted signal is switched to a non-compliant output, a red screen alert or muted screen will appear.

## 10.2.1. Protected and Unprotected Content

Many video sources send HDCP protected signal if they detect that the sink is HDCP capable – even if the content is not copyrighted. This can cause trouble if an HDCP capable device is connected between the source and the display. In this case, the content cannot be viewed on non-HDCP capable displays and interfaces like event controllers. Rental and staging technicians often complain about certain laptops, which are always sending HDCP encrypted signals if the receiver device (display, matrix router, etc.) reports HDCP compliancy. However, HDCP encryption is not required all the time e.g. computer desktop image, certain laptops still do that.

To avoid unnecessary HDCP encryption, Lightware introduced the HDCP enabling/disabling function: the HDCP capability can be disabled in the Lightware device. If HDCP is disabled, the connected source will detect that the sink is not HDCP capable, and turn off authentication.

#### 10.2.2. Disable Unnecessary Encryption

#### **HDCP Compliant Sink**



All the devices are HDCP-compliant, no manual setting is required, both protected and unprotected contents are transmitted and displayed on the sink.

#### Not HDCP-compliant Sink 1.



Non-HDCP compliant sink is connected to the receiver. Some sources (e.g. computers) always send HDCP encrypted signals if the receiver device reports HDCP compliancy, however, HDCP encryption is not required all the time (e.g. computer desktop image). If HDCP is enabled in the receiver, the image will not be displayed on the sink.

Setting the HDCP parameter to Auto on the output port and disable HDCP on the input port, the transmitted signal will not be encrypted if the content is not protected. Thus, non-HDCP compliant sinks will display non-encrypted signal.

#### Not HDCP-compliant Sink 2.



The layout is the same as in the previous case: non-HDCP compliant display device is connected to the receiver but the source would send protected content with encryption. If HDCP is enabled on the input port of the receiver, the source will send encrypted signal. The sink is not HDCP compliant, thus, it will not display the video signal (but blank/red/muted/etc. screen). If HDCP is disabled on the input port of the receiver, the source will not send the signal. The solution is to replace the display device to an HDCP-capable one.

76


## 10.3. Pixel Accurate Reclocking

Signal reclocking is an essential important procedure in digital signal transmission. After passing the reclocking circuit, the signal becomes stable, jitter-free, and can be transmitted over more equipment like processors, or event controllers. Without reclocking, sparkles, noise, and jaggies appear on the image.

Lightware's sophisticated Pixel Accurate Reclocking technology fixes more problems than general TMDS reclocking. It removes not only intra-pair skew but inter-pair skew as well. The Pixel Accurate Reclocking circuit eliminates the following errors:


#### Intra-pair skew

Skew between the + and - wires within a differential wire pair (e.g. Data2- and Data2+). It's caused by different wire lengths or slightly different wire construction (impedance mismatch) in DVI cable. It results in jitter.




## Inter-pair skew

Skew between two differential wire pairs in a cable. It is caused by different wire pair lengths or different number of twists in the DVI cable. Too much inter-pair skew results color shift in the picture or sync loss.




#### **Jitter**

Signal instability in the time domain. The time difference between two signal transitions should be a fixed value, but noise and other effects cause variations.



#### Noise

Electromagnetic interference between other electronic devices such as mobile phones, motors, etc. and the DVI cable are coupled onto the signal. Too much noise results in increased jitter.





# **Appendix**

## Tables, drawings, guides, and technical details as follows:

- SPECIFICATION
- ► INPUT/OUTPUT PORT NUMBERING
- ► CONTENT OF BACKUP FILE
- ► FACTORY DEFAULT SETTINGS
- ► MAXIMUM EXTENSION DISTANCES
- ► MECHANICAL DRAWINGS
- ► AUDIO CABLE WIRING GUIDE
- ► FACTORY EDID LIST
- ► FURTHER INFORMATION

# 11.1. Specification

## General

	Compliance	CE
	EMC compliance (emission)	IEC/EN 55032:2015
	EMC compliance (immunity)	IEC/EN 55024:2011
	Warranty	3 years
	Cooling	Passive
	Operating temperature	0 to +50°C (+32 to +122°F)
	Operating humidity	10% to 90%, non-condensing
Po	ower	
	Power supply External pov	wer adaptor or PoE remote powering
	Power adaptorIn 100-	240 V AC 50/60 Hz, Out 12V DC, 2 A
	Power connector	Locking DC connector (2.1 mm pin)
	Power over TPS	DC 48V, 1A (IEEE 802.3af)
	Power consumption	10 W (typ)
En	nclosure	
	Rack mountable	Yes
	Material	1 mm steel
	Dimensions in mm	221W x 100.4D x 26H
	Dimensions in inch	8.7 W x 3.95 D x 1.02 H
	Weight	607 g
Αι	ıdio/Video Ports	
	HDCP compliant	Yes, HDCP 1.4
	TPS Input Port	
	TPS port connector type	RJ45 connector
	Power over Ethernet (PoE)	Yes (IEEE 802.3af)
	Compliance	HDBaseT™
	Transferred signals (TPS) Vic	leo, Audio, RS-232, Infrared, Ethernet
	Max. video resolutions	1920x1080@120 Hz, 24 bit
		1600x1200@60 Hz, 36 bit
		3840x2160@30 Hz, 24 bit

Audio formats	8 channel PCN
	Dolby TrueH[
	DTS-HD Master Audio 7.
Reclocking	Pixel Accurate Reclocking
HDCP compliant	Ye:
HDMI Output Port	
HDMI port connector type	19-pole HDMI Type A receptacle
Standard	DVI 1.0, HDMI 1.4
Max. video resolutions	1920x1080@120 Hz, 24 bi
	1600x1200@60 Hz, 36 bi
	3840x2160@30 Hz, 24 bi
Audio formats	8 channel PCN
	Dolby TrueHI
	DTS-HD Master Audio 7.
Reclocking	Pixel Accurate Reclocking
HDCP compliant	Ye
Analog Audio Output Port	
Audio port connector	5-pole Phoenix connecto
Signal transmission	Balanced and unbalanced audio
Volume	95.62 – 0 dl
itrol Ports	
RS-232 Control	
	3-pole Phoenix connecto
Available Baud rates	between 4800 and 115200
Available Data bits	8 or <sup>.</sup>
Available Parity	None / Odd / Eve
	1 / 1.5 / 3
JSB Control	
JSB connector	USB mini B type
JSB 2.0 compliance	Ye

#### Infrared Control

Number of IR ports	2 (1x RX, 1x TX)
Connector type 3.5mm TRS (approx. 1/8"	jack) Ethernet Control
Connector type	Locking RJ45
Ethernet data rate10/100Base-T, full	duplex with autodetect
Power over Ethernet (PoE)	Not supported
Relay Port	
Port connector4-p	oole Phoenix connector
Number of relays	2
TypeN	lormally open contacts
Maximum ratings	30 V, 1 A, AC/DC
Default connection state	Open

## 11.2. Input/Output Port Numbering

The following table contains the input and output ports with their ID numbers which shall be used when protocol command sending or in Lightware Device Controller.

## **Audio/Video Ports**

Port name	Video port nr.		Emulated EDID	Audio port nr.	
Portifiante	LW2	LW3	memory	LW2	LW3
TPS Link in	1	I1	E1	1	I1
HDMI out	1	01	-	1	01
Audio out	-	-	-	2	02

## **RS-232 Ports**

Port name	Port nr. (LW2 / LW3)
Local	P1
TPS link	P2

## **Infrared Ports**

Port name	Port nr. (LW3)
Local IR input	S1
Local IR output	D1
TPS link input	S2
TPS link output	D2

# 11.3. Content of Backup File

The backup file contains numerous settings and parameters saved from the device. When the file is uploaded to a device, the followings will be overwritten:

TPS input port						
Video port name, Audio port name, HDCP setting						
Ethernet port name, Ethernet port status (enable / disable)						
Remote port name, Remote port status (enable / disable)						
Analog audio output port						
Port name, Volume, Balance						
HDMI output port						
Port name, HDCP mode, HDMI mode, Power +5V mode						
Test pattern mode, clock source, and type						
Audio port name, Audio output enabled, S/PDIF mode						
Port parameters						
Mute video ports						
Mute audio ports, Lock audio ports						
Local and TPS serial port						
RS-232 mode, Control protocol, Baud rate, Data bits, Stop bits, Parity						
Port name and CI (Command Injection) port number						
Local and TPS IR port						
Port status (enable / disable), Code length, Repetition code, Enable modulation						
Input port name, Output port name						
CI status (enable / disable), CI port number						
USB port						
Port name, Port status (enable / disable)						
Relay ports						
Port name, Connection state						
Network settings						
DHCP status (enable / disable)						
Static IP address, Network mask, Gateway address						
Further settings						
User EDID data (U1-U15)						
Event manager: settings of all Events (E1-E100)						

## 11.4. Factory Default Settings

Video port settings S mode CP Enable St pattern mode St pattern clock source St pattern	ys on dB (100%)							
S mode CP Enable St pattern mode St pattern clock source St pattern St patter	ys on dB (100%)							
CP Enable of pattern mode Disable of pattern clock source 480p of pattern Bar tput HDMI mode Auto tput HDCP mode Auto wer 5V mode Always Analog audio port settings lume 0.00 celement with the pattern of the pattern o	ys on dB (100%)							
st pattern mode st pattern clock source st pattern st p	ys on dB (100%)							
st pattern clock source st pattern st patter	ys on dB (100%)							
test pattern tput HDMI mode tput HDCP mode Auto Alway  Analog audio port settings Analog audio port se	dB (100%)							
tput HDMI mode Auto tput HDCP mode Auto wer 5V mode Alway	dB (100%)							
tput HDCP mode Alway  Analog audio port settings  Jume 0.00 cele  Network settings  address 192.1 bnet mask 255.2 bnet mask 255.2 ctic gateway 192.1 CP Disab rt numbers (LW2 / LW3 / HTTP) 1000 S Ethernet status Enable  Relay port settings  nnection state Open	dB (100%)							
Analog audio port settings           lume         0.00 d           lance         0 (cer           Network settings           address         192.1           bnet mask         255.2           atic gateway         192.1           CP         Disability           rt numbers (LW2 / LW3 / HTTP)         1000           S Ethernet status         Enable           Relay port settings           nnection state         Open	dB (100%)							
Analog audio port settings  Jume 0.00 celegrater of the settings of the setting of the sett	dB (100%)							
Network settings	• •							
Network settings	• •							
Network settings address 192.1 bnet mask 255.2 britic gateway 192.1 CP Disab rt numbers (LW2 / LW3 / HTTP) 1000 S Ethernet status Enable Relay port settings nnection state Open	nter)							
address 192.1 bnet mask 255.2 britic gateway 192.1 CP Disab rt numbers (LW2 / LW3 / HTTP) 1000 S Ethernet status Enabl Relay port settings nnection state Open								
binet mask 255.2 htic gateway 192.1 CP Disab rt numbers (LW2 / LW3 / HTTP) 1000 S Ethernet status Enable Relay port settings nnection state Open								
tric gateway  CP Disable trinumbers (LW2 / LW3 / HTTP)  S Ethernet status  Relay port settings  nnection state  Open	68.0.100							
CP Disable triangle price (LW2 / LW3 / HTTP) 1000 S Ethernet status Enable Relay port settings nnection state Open	255.255.0							
rt numbers (LW2 / LW3 / HTTP) 1000 S Ethernet status Enab Relay port settings nnection state Open	192.168.0.1							
Relay port settings nnection state  Denote  Open	Disabled							
Relay port settings nnection state Open	10001 / 6107 / 80							
nnection state Open	Enabled							
RS-232 settings								
ntrol protocol LW2								
ud rate 5760	0							
tabits 8								
rity No								
opbits 1								
eration mode (Link and Local) Pass-	through							
mmand injection port nr. (Local / TPS) 8001	/ 8002							
IR port settings								
mmand injection status Enab	lad							
mm. inj. input port nr. (Local / TPS) 9001	leu							
mm. inj. output port nr. (Local / TPS) 9003	/ 9002							

## 11.5. Maximum Extension Distances


	Pixel clock	Cable lengths ( Auto / Longreach TPS mode)					
Resolution	rate	CAT5e AWG24	CAT7 AWG26**	CAT7 AWG23			
1024x768@60Hz	65 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*			
1280x720p@60Hz	73.8 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*			
1920x1080p@60Hz / 24bpp	148.5 MHz	100 m / 130 m*	90 m / 120 m*	120 m / 170 m*			
1920x1200@60Hz	152.9 MHz	100 m / NA	90 m / NA	120 m / NA			
1600x1200@60Hz	162 MHz	100 m / NA	90 m / NA	120 m / NA			
1920x1080@60Hz / 36bpp	223.6 MHz	70 m / NA	70 m / NA	100 m / NA			
3840x2160@30Hz UHD	297 MHz	70 m / NA	70 m / NA	100 m / NA			
4096x2160@30Hz 4K	297 MHz	70 m / NA	70 m / NA	100 m / NA			

<sup>\*</sup> With Long reach operation mode which supports pixel clock frequencies up to 148.5 MHz.


## 11.6. Mechanical Drawings

The following drawings present the physical dimensions of the receiver. Dimensions are in mm.


#### **Bottom View**



#### Front View




## **Top View**



#### **Rear View**



## Side View



<sup>\*\*</sup> When remote powering is used with AWG26 cables, distances are 20% shorter.

## 11.7. Audio Cable Wiring Guide

Inputs and outputs of audio devices are symmetric or asymmetric. The main advantage of the symmetric lines is the better protection against the noise therefore, they are widely used in the professional audio industry. Symmetric audio is most often referred to as balanced audio, as opposed to asymmetric, which is referred to as unbalanced audio. Lightware products are usually built with 5-pole Phoenix connectors so we would like to help users assembling their own audio cables. See the most common cases below.

**ATTENTION!** Symmetric and asymmetric lines can be linked with passive accessories (e.g. special cables), but in this case half of the line level is lost.

**ATTENTION!** There are numerous types of regularly used connector and cable types to connect audio devices. Please always make sure that a connector or cable fits your system before use.

**ATTENTION!** Never join the phase-inverted (negative, cold or -) poles (either right and left) to the ground or to each other on the output side, as this can damage the unit.

INFO: Use a galvanic isolation in case of a ground loop.

## The Pinout of the 5-pole Phoenix Connector




Pin nr.	Signal
1	Left+
2	Left-
3	Ground
4	Right-
5	Right+





## **Compatible Plug Type**

Phoenix® Combicon series (3.5mm pitch, 5-pole), type: MC1.5/5-ST-3.5.


#### From Unbalanced Output to Balanced Input










#### From Balanced Output to Unbalanced Input











## From Balanced Output to Balanced Input











# 11.8. Factory EDID List

Mem.		Resc	olution		Туре	Mem.		Resc	olution		Туре
F1	640 x	480	@ 60.00	Hz	D	F34	720 x	576	@ 50.00	Hz	Н
F2	848 x	480	@ 60.00	Hz	D	F35	1280 x	720	@ 50.00	Hz	Н
F3	800 x	600	@ 60.32	Hz	D	F36	1280 x	720	@ 60.00	Hz	Н
F4	1024 x	768	@ 60.00	Hz	D	F37	1920 x	1080i	@ 50.04	Hz	Н
F5	1280 x	768	@ 50.00	Hz	D	F38	1920 x	1080i	@ 50.00	Hz	Н
F6	1280 x	768	@ 59.94	Hz	D	F39	1920 x	1080i	@ 60.05	Hz	Н
F7	1280 x	768	@ 75.00	Hz	D	F40	1920 x	1080i	@ 60.05	Hz	Н
F8	1360 x	768	@ 60.02	Hz	D	F41	1920 x	1080	@ 24.00	Hz	Н
F9	1280 x	1024	@ 50.00	Hz	D	F42	1920 x	1080	@ 25.00	Hz	Н
F10	1280 x	1024	@ 60.02	Hz	D	F43	1920 x	1080	@ 30.00	Hz	Н
F11	1280 x	1024	@ 75.02	Hz	D	F44	1920 x	1080	@ 50.00	Hz	Н
F12	1400 x	1050	@ 50.00	Hz	D	F45	1920 x	1080	@ 60.00	Hz	Н
F13	1400 x	1050	@ 60.00	Hz	D	F46	1920 x	1080	@ 60.00	Hz	Н
F14	1400 x	1050	@ 75.00	Hz	D	F47	Universal_	HDMI_P	СМ		Н
F15	1680 x	1050	@ 60.00	Hz	D	F48	Universal_	HDMI_A	LL		Н
F16	1920 x	1080	@ 50.00	Hz	D	F49	Universal_	HDMI_D	С		Н
F17	1920 x	1080	@ 60.00	Hz	D	F50-F89	Reserved				
F18	2048 x	1080	@ 50.00	Hz	D	F90	1920 x	2160	@ 59.99	Hz	D
F19	2048 x	1080	@ 60.00	Hz	D	F91	1024 x	2400	@ 60.01	Hz	D
F20	1600 x	1200	@ 50.00	Hz	D	F92-F93	Reserved				
F21	1600 x	1200	@ 60.00	Hz	D	F94	2048 x	1536	@ 60.00	Hz	D
F22	1920 x	1200	@ 50.00	Hz	D	F95	Reserved				
F23	1920 x	1200	@ 59.56	Hz	D	F96	2560 x	1600	@ 59.86	Hz	D
F24	2048 x	1200	@ 59.96	Hz	D	F97	3840 x	2400	@ 24.00	Hz	D
F25-F28	Reserved					F98	1280 x	720	@ 60.00	Hz	H3D
F29	Universal_	DVI			D	F99	1920 x	1080	@ 60.00	Hz	H3D
F30	1440 x	480i	@ 60.05	Hz	Н	F100	1024 x	768	@ 60.00	Hz	Н
F31	1440 x	576i	@ 50.08	Hz	Н	F101	1280 x	1024	@ 50.00	Hz	Н
F32	640 x	480	@ 59.95	Hz	Н	F102	1280 x	1024	@ 60.02	Hz	Н
F33	720 x	480	@ 59.94	Hz	Н	F103	1280 x	1024	@ 75.02	Hz	Н

Mem.		Resc	lution		Туре	Mem.	Resolution	Туре
F104	1600 x	1200	@ 50.00	Hz	Н			
F105	1600 x	1200	@ 60.00	Hz	Н			
F106	1920 x	1200	@ 59.56	Hz	Н			
F107	2560 x	1440	@ 59.95	Hz	Н			
F108	2560 x	1600	@ 59.86	Hz	Н			
F109	3840 x	2400	@ 24.00	Hz	Н			
F110	3840 x	2160	@ 24.00	Hz	Н			
F111	3840 x	2160	@ 25.00	Hz	Н			
F112	3840 x	2160	@ 30.00	Hz	Н			
F113-F117	Reserved							
F118	Universal_4K_PCM				H4K			
F119	Universal_4K_ALL				H4K			
F120	3840 x	2160	@ 60.00	Hz	H4K			

## Legend

Туре	Description						
D	DVI EDID						
Н	HDMI EDID						
Α	Analog EDID						
DL	Dual-Link DVI EDID						
H3D	HDMI EDID with 3D support						
H4K HDMI EDID with 4K resolution support							

## 11.9. Further Information

#### **Limited Warranty Statement**

- 1. Lightware Visual Engineering LLC (Lightware) warrants to all trade and end user customers that any Lightware product purchased will be free from manufacturing defects in both material and workmanship for three (3) years from purchase unless stated otherwise below. The warranty period will begin on the latest possible date where proof of purchase/delivery can be provided by the customer. In the event that no proof can be provided (empty 'Date of purchase' field or a copy of invoice), the warranty period will begin from the point of delivery from Lightware.
- 1.1. 25G and MODEX product series will be subject to a seven (7) year warranty period under the same terms as outlined in this document.
- 1.2. If during the first three (3) months of purchase, the customer is unhappy with any aspect of a Lightware product, Lightware will accept a return for full credit.
- 1.3. Any product that fails in the first six (6) months of the warranty period will automatically be eligible for replacement and advanced replacement where available. Any replacements provided will be warranted for the remainder of the original unit's warranty period.
- 1.4. Product failures from six (6) months to the end of the warranty period will either be repaired or replaced at the discretion of Lightware. If Lightware chooses to replace the product then the replacement will be warranted for the remainder of the original unit's warranty period.
- 2. The above-stated warranty and procedures will not apply to any product that has been:
- 2.1. Modified, repaired or altered by anyone other than a certified Lightware engineer unless expressly agreed beforehand.
- 2.2. Used in any application other than that for which it was intended.
- 2.3. Subjected to any mechanical or electrical abuse or accidental damage.
- 2.4. Any costs incurred for repair/replacement of goods that fall into the above categories (2.1., 2.2., 2.3.) will be borne by the customer at a pre-agreed figure.
- 3. All products to be returned to Lightware require a return material authorization number (RMA) prior to shipment and this number must be clearly marked on the box. If an RMA number is not obtained or is not clearly marked on the box, Lightware will refuse the shipment.
- 3.1. The customer will be responsible for in-bound and Lightware will be responsible for out-bound shipping costs.
- 3.2. Newly repaired or replaced products will be warranted to the end of the originally purchased products warranty period.

#### **Document Revision History**

Rev.	Release date	Changes	Editor
1.0	22-12-2016	Initial version	Tamas Forgacs
1.1	06-02-2017	Added detailed audio function description in LW3 programmer's reference, added RS-232 commands in LW2 programmer's reference	Tamas Forgacs
2.0	19-09-2017	New document format, updated LW3 prog. ref. chapter	Tamas Forgacs
2.1	04-12-2017	Major updates for firmware v1.2.0, updated Troubleshooting chapter	Tamas Forgacs
2.2	31-10-2018	1080p120Hz signal support info added	Judit Barsony

#### Contact Us

sales@lightware.com

+36 1 255 3800

support@lightware.com

+36 1 255 3810

Lightware Visual Engineering LLC.

Peterdy 15, Budapest H-1071, Hungary

www.lightware.com

©2018 Lightware Visual Engineering. All rights reserved. All trademarks mentioned are the property of their respective owners. Specifications subject to change without notice.