

# Advanced Control Lightware Devices for Cisco Room Integration

LEVEL UP

**The Corporate Standard**



Add a **Lightware device with Event Manager** to your Cisco Telepresence kit to get **local and remote multiport inputs** and **room automation control**, and **manage everything** from the system's **native touch panel**. We provide **full support** for the integration into target Cisco systems.

Cisco **Touch 10** with UM-X-TPS-TX140-Plus



**Multiport local and remote inputs**



**Native Cisco Touch 10 room control**




**Easy installation**

# The Lightware Advantage in your Cisco Room:


Control integrated Lightware devices natively from a Cisco touch panel




A single smart extender or matrix router can enhance your Cisco configuration with **multiport input** options for remote and local sources



**Open API:**  
easy integration of built-in **room control** including lights, screens, projectors and other elements.



**Control** connected **media devices**  
via **CEC** and **IR**



# Advanced Control Devices: **‘PLUS’** Extenders and Matrix Routers with Event Manager

To further improve services and help the integration process, we have developed and offer new Advanced Control smart TPS extenders and matrix routers with a wide range of control options including support for Cisco password login, CEC and IR controls.



- Support RS-232 protocol for communication and control of third party devices like VC codecs. This allows the Cisco Room Kit login on RS-232–USB connection.
- Support to receive CEC commands for control of displays and Lightware Event Manager to automate room actions
- Support to send CEC commands on HDMI ports for control of other devices
- Support true Infrared messages using HEX codes to control TVs, media players and other devices with IR emitters
- 100 available event slots in 'Plus' extenders



# Use our online **Cisco** Room Configuration Wizard for easy setup

1. Browse to Support/Cisco Room Configuration Wizard on the lightware.com webpage
2. Select your Cisco Room Kit type
3. Select the Lightware device to integrate
4. Select, add and adjust additional room control elements
5. Check the generated system schematic and download the configuration file; you may also print the step-by-step guide
6. Configure the system by uploading the configuration file to the Lightware device
7. You can now use the Cisco system with your custom room control and input buttons

Our freely accessible online Cisco Room Configuration Wizard is easy to use and greatly helps the **integration of Lightware devices by guiding users** through the steps of creating the required configuration file for the selected devices and the room environment.



Note: Tested with Google Chrome, Safari, Firefox and Microsoft Edge browsers.  
Best experience with the step by step guide print: Google Chrome.  
Version: v1.1.0 (01/02/2019)

[Leave Feedback](#)

## Currently available products with **'Advanced Control'** pack:

Product	Advanced Control Pack
MMX8x4-HT420M	Included
MMX8x4-HT400MC	Included
MMX8x8-HDMI-4K-A	Included
MMX4x2-HT200	Included
MMX4x2-HDMI	Included
UMX-TPS-TX140-Plus	As a new 'Plus' product
UMX-HDMI-140-Plus	As a new 'Plus' product
SW4-TPS-TX240-Plus	As a new 'Plus' product
WP-UMX-TPS-TX130-Plus	As a new 'Plus' product
HDMI-TPS-RX110AY-Plus	As a new 'Plus' product